



brother Information for compliance with Commission Regulation 801/2013

Model Name: QL-1110NWB


Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.3W	0.3W	0min	-
USB	1.3W	0.3W	0min	240min
Wi-Fi	1.5W	0.3W	0min	-
Bluetooth	1.2W	0.3W	0min	-
All network ports activated and connected	1.8W	0.3W	0min	

How to enable/disable Wi-Fi

To activate the wireless function



Press and hold the  (Power) button to turn the Label Printer on, and then press and hold the  (Wi-Fi) button.

To deactivate the wireless function

Press and hold the  (Wi-Fi) button again to turn the wireless function off.

How to enable/disable Bluetooth

To activate the Bluetooth function

Press and hold the  (Power) button to turn the Label Printer on, and then press and hold the  (Bluetooth) button.

To deactivate the Bluetooth function

Press and hold the  (Bluetooth) button again to turn the Bluetooth function off.



brother Information for compliance with Commission Regulation 801/2013

Model Name: QL-1110NWBc

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.3W	0.3W	3min	-
USB	1.3W	0.3W	3min	240min
Wi-Fi	1.6W	0.3W	0min	-
Bluetooth	1.2W	0.3W	3min	-
All network ports activated and connected	1.8W	0.3W	0min	

How to enable/disable Wi-Fi

To activate the wireless function



Press and hold the  (Power) button to turn the Label Printer on, and then press and hold the  (Wi-Fi) button.

To deactivate the wireless function

Press and hold the  (Wi-Fi) button again to turn the wireless function off.

How to enable/disable Bluetooth

To activate the Bluetooth function

Press and hold the  (Power) button to turn the Label Printer on, and then press and hold the  (Bluetooth) button.

To deactivate the Bluetooth function

Press and hold the  (Bluetooth) button again to turn the Bluetooth function off.