

**Model Name: RJ-4230B**

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB Port	1.4W	0.3W	0min	60min
Bluetooth	1.5W	0.3W	0min	60min
All network ports activated and connected	1.6W	0.3W	0min	60min

## How to enable/disable Bluetooth

### To activate the Bluetooth function:

1. Press and hold the ⏻ (Power) button to turn the Label Printer on.
2. Press the Menu button.
3. Press the [▲] or [▼] button to select the [Bluetooth] menu, and then press the [OK] button.
4. Press the [▲] or [▼] button to select [Bluetooth (On/Off)], and then press the [OK] button.
5. Press the [▲] or [▼] button to select [On], and then press the [OK] button.

### To deactivate the Bluetooth function:

1. Press and hold the ⏻ (Power) button to turn the Label Printer on.
2. Press the Menu button.
3. Press the [▲] or [▼] button to select the [Bluetooth] menu, and then press the [OK] button.
4. Press the [▲] or [▼] button to select [Bluetooth (On/Off)], and then press the [OK] button.
5. Press the [▲] or [▼] button to select [Off], and then press the [OK] button.