

brother

RD
ROLLS



D016GL001

RJ-4250WB/4230B

Product Safety Guide (English)

Be sure to read this document before using the printer.

We recommend that you keep this document nearby for future reference.

- For servicing, adjustments or repairs, contact Brother customer service or your local Brother dealer.
- If the printer operates abnormally or any error occurs, turn off the printer, disconnect all cables and contact Brother customer service or your local Brother dealer.
- The information provided in this document is subject to change without notice.
- Unauthorised duplication or reproduction of any or all contents of this document is prohibited.
- Please note that we cannot assume any responsibility for any damage or lost profit arising from the use of labels created with this printer, the disappearance or change of data due to failure, repair or consumables while using the battery, or any claim from a third party.

⚠ DANGER

Failure to observe instructions and warnings will result in death or serious injuries. Follow these guidelines to avoid the risk of heat generation, smoking, explosion, or fire.

Rechargeable Li-ion Battery

- Do not allow the battery to come into contact with liquids.
- Do not charge, use, or leave the battery in high temperature locations (above 60 °C).
- Do not attempt to charge the battery using an unsupported charger.
- Use only for its intended purpose.
- Keep away from heat and fire.
- Do not connect the + and - terminals with metal objects such as wire. Do not carry or store the battery with metal objects.
- Do not throw, hit or damage the battery in any way.
- Do not solder any connections to the battery.
- Do not disassemble or modify the battery.
- Do not dispose of the battery with household waste.

⚠ WARNING

Failure to observe instructions and warnings could result in death or serious injuries. Follow these guidelines to avoid the risk of heat generation, smoking, explosion, fire, or injury.

Printer, AC Adapter (Optional), or Car Adapter (Optional)

- If foreign objects are inserted into the printer or its connectors and ports, stop using the printer and turn off the power. Then disconnect all cables or remove the battery.
- Do not use, charge and store the product:
 - Where liquids may come into contact.
 - Where condensation forms.
 - Where there is a lot of dust.
 - Where the temperature is extremely high.
 - During a thunderstorm.
- Do not disassemble or alter the product.
- Do not pour chemicals or use combustible sprays on the product.
- Do not use or store the printer, other components, or packaging within the reach of children.
- Remove the battery or disconnect the cables when shipping.
- If the printer is not in use for long periods, remove the battery or disconnect the cables before storing.

Rechargeable Li-ion Battery

- Keep away from infants. If ingested, contact emergency services immediately.
- Stop using the battery if there are noticeable abnormalities such as smell, heat, deformities, or discoloration.
- If liquid from the battery gets into eyes, wash them immediately with clean water. Contact emergency services immediately.

AC Adapter, Car Adapter

- Use only with the specified product.
- Insert the plug firmly into the socket.
- Use the AC adapter with standard electrical sockets (AC 100-240 V 50/60 Hz) and the Car adapter with DC 12 V supplies.
- Do not allow metal objects to come into contact with connectors and ports.
- Do not pull on the cable when disconnecting the AC adapter cord or Car adapter from the electrical socket. Hold the plug and pull it out of the electrical socket.
- Do not damage, twist, severely bend, pull on, place objects on, or bind the AC adapter or Car adapter.
- Do not allow the AC adapter and Car adapter cables to be pinched.
- Do not overload electrical sockets.


⚠ CAUTION

Failure to observe instructions and warnings could result in minor or moderate injuries.

Follow these guidelines to avoid injury.

Printer

- Do not hold the printer by the RD Roll compartment cover or the roll guide. There is a risk that the cover could detach or the printer could fall.
- When connecting cables and accessories, follow the applicable instructions.
- Do not touch the print head or metal parts surrounding the head.
- If the printer is used for a long period of time, the parts of the printer shown may become hot enough to cause a low temperature burn.



Rechargeable Li-ion Battery

If liquid from the battery gets onto skin or clothes, immediately rinse with water.

AC Adapter, Car Adapter


Make sure you can always access the cable of the adapter so that you can disconnect it immediately in an emergency.

Belt Clip

Make sure that the belt clip is attached securely to the printer and the wearer's belt.

Warning Label

Do not touch the blade or print head.



General Precautions

Printer, AC Adapter, Car Adapter, or Accessories

Observe all applicable regulations when disposing of these products.

For Australia Only:

Support - For technical support of your Brother Product other than what you can resolve through the User's Guide, please visit our Web Site or Solutions Web Site (see below) to find an answer to FAQs/Troubleshooting, locating Drivers & Software. Alternatively, please contact the Product Support Centre for any customer care/technical support enquiry.

To contact Brother International (Aust) Pty Ltd for support on a Brother product please see the details listed below:

Product Support Centre: **Australia**

Brother International (Aust) Pty Ltd

Phone: 02 8875 6000

Fax: 02 9870 7223

Solutions Site: support.brother.com

Web Site: www.brother.com.au

E-mail: To submit an e-mail enquiry, visit www.brother.com.au go to

Service and Support area and follow the prompts.

Our Technical Support Consultants are available 5 days a week by phone during the hours of 8.30am to 5.00pm (AEST/AEDT) Monday to Friday.

Regulation

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED WITH AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Open Source Licensing Remarks

This product includes open source software.

To see the Open Source Licensing Remarks, go to your model's Manuals page on the Brother Solutions Center at support.brother.com.