



Information for compliance with Commission Regulation 801/2013

Model Name: TD-2125NWB, TD-2135NWB

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.4 W	0.3 W	0 min	60 min
USB Port1	1.2 W	0.3 W	0 min	60 min
USB Port2	1.4 W	0.3 W	0 min	60 min
Wi-Fi	1.8 W	0.3 W	0 min	60 min
Bluetooth	1.5 W	0.3 W	0 min	60 min
RS-232C	1.2 W	0.3 W	0 min	60 min
All network ports activated and connected	2.0 W	0.3 W	0 min	60 min

How to enable/disable Wireless LAN & Bluetooth

To activate the Wireless/Bluetooth function:

Press and hold the Power button to turn the printer on, and then press and hold the feed button for 5 seconds.

To deactivate the Wireless/Bluetooth function:

Press and hold the Power button to turn the printer on, and then press and hold the feed button for 5 seconds while the Wi-Fi LED and Bluetooth LED are lit on or blinking.