brother

HL-L9200CDW

Quick Setup Guide

The latest manuals are available at Brother Solutions Center: http://solutions.brother.com/.
Not all models are available in all countries.

Version 0
CHN-ENG

Unpack the machine and check the components

Drum Unit
(pre-installed)

Waste Toner Box
(pre-installed)

USB Interface Cable

Quick Setup Guide

Toner Cartridges
(Black, Cyan, Magenta and Yellow; pre-installed)

Belt Unit
(pre-installed)

Power Cord

CD-ROM

Product Safety Guide

Read the Product Safety Guide first, and then read this Quick Setup Guide for the correct installation procedure.

NOTE:
• For a network connection you will need to purchase a network interface cable. Please use the supplied USB cable for a USB connection.
  USB cable
  We recommend using a USB2.0 cable (Type A/B) that is no more than 2 meters long.
  Network cable
  Use a straight-through Category 5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.

1 Remove the packing material from the machine

2 Load paper in the paper tray

Adjust the paper guides.

## 3 Connect the power cord and turn on the machine

4 Select your language

1. Press ▮▮ > General Setup > Local Language.

2. Press your language.

3. On the machine's Touchpanel, press ⌂.

5 Configuration using the CD-ROM (Windows®)

HL-XXXX Color Printer Utilities   brother

Top Menu

Install Printer Driver
User's Guides
Custom Installation
Brother Support
On-Line Registration

© 2001-2014 Brother Industries, Ltd. All Rights Reserved.   Back   Exit

Follow the on-screen instructions until the **Connection Type** screen appears.

Brother Printing Device Installation

Connection Type

Select the connection type of the device you want to install, and then click Next.If you want to install the PS driver (Brother's BR-Script Driver), choose Custom install.

- Local Connection (USB)
  - Custom Install
- Wired Network Connection (Ethernet)
  - Custom Install
- Wireless Network Connection
  - Custom Install

InstallShield

Back   Next   Cancel

For USB Connection

For Wired Network Connection
Connect a network cable first.

For Wireless Network Connection

Follow the on-screen instructions to continue the installation.

Finish

NOTE:
If connection is unsuccessful, repeat this step.

Wireless Network Connection

Wireless Device Setup Wizard

Wireless Device Setup

Using a USB cable temporarily connected to your wireless computer is the recommended wireless installation method.

Do you have a USB cable?

- Yes, I have a USB cable to use for installation.
- No, I do not have a USB cable.
  Note: If you do not have a USB cable you can still setup your device wirelessly (Advanced Method).

Back   Next   Cancel

[Recommended]
Temporarily use a USB cable for easy setup.

[Option]
Select if you do not have a USB cable.

Follow the on-screen instructions to continue the installation.

Finish

NOTE:
If connection is unsuccessful, repeat this step.

Configuration without using the CD-ROM (Windows® without CD-ROM drive or Macintosh)

Download the full driver and software package from the Brother Solutions Center.
(For Windows®) solutions.brother.com/windows
(For Macintosh) solutions.brother.com/mac

---

Print using your mobile device

Print from your mobile devices using our free application "Brother iPrint&Scan".

1. Connect the machine and wireless LAN access point/router from the machine's Touchscreen.

Press WiFi .

Press Setup Wizard.

Press Yes for Wireless Network.

Select the specified SSID, and then enter the Network key.

2. Download "Brother iPrint&Scan" to start using your machine with mobile devices.
solutions.brother.com/ips

Finish