brother

MFC-L8600CDW / MFC-L8850CDW

Quick Setup Guide

The latest manuals are available at Brother Solutions Center: http://solutions.brother.com/.

Version 0
TWN-ENG

Unpack the machine and check the components

Drum Unit
(pre-installed)

Waste Toner Box
(pre-installed)

USB Interface Cable

Quick Setup Guide

Telephone Line Cord

Product Safety Guide

Toner Cartridges
(Black, Cyan, Magenta and Yellow;
pre-installed)

Belt Unit
(pre-installed)

Power Cord

Basic User's Guide

CD-ROM

Read the Product Safety Guide first, and then read this Quick Setup Guide for the correct installation procedure.

NOTE:
- The illustrations in this Quick Setup Guide are based on the MFC-L8850CDW.
- For a network connection you will need to purchase a network interface cable. Please use the supplied USB cable for a USB connection.

  USB cable
 We recommend using a USB 2.0 cable (Type A/B) that is no more than 2 meters long.

  Network cable
  Use a straight-through Category 5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.

---

1 Remove the packing material from the machine

## 2 Load paper in the paper tray

---

## 3 Connect the power cord and turn on the machine

---

4 Select your language (if needed)

You can set the language of the Touchscreen in Simplified-Chinese and English.

1. Press 🔧 > All Settings > Initial Setup > Local Language

2. Press your language.

3. Press 🏠.

Adobe Flash Player 10

XXX-XXXX   Multi-Function Center   **brother**

Top Menu

Install MFL-Pro Suite
Full Driver & Software Package
(includes Wireless & Wired Network Setup)

User's Guides

Custom Installation

Additional Applications

Brother Support

On-Line Registration

© 2001-2014 Brother Industries, Ltd. All Rights Reserved.   Back   Exit

Follow the on-screen instructions until the **Connection Type** screen appears.

Brother Printing Device Installation

Connection Type

Select the connection type of the device you want to install, and then click Next.If you want to install the PS driver (Brother's BR-Script Driver), choose Custom install.

Local Connection (USB)
☐ Custom Install

Wired Network Connection (Ethernet)
☐ Custom Install

Wireless Network Connection
☐ Custom Install

InstallShield

< Back   Next >   Cancel

For USB Connection

For Wired Network Connection
Connect a network cable first.

For Wireless Network Connection

Follow the on-screen instructions to continue the installation.

Finish

NOTE:
If connection is unsuccessful, repeat this step.

Wireless Network Connection

Wireless Device Setup Wizard

Wireless Device Setup

Using a USB cable temporarily connected to your wireless computer is the recommended wireless installation method.

Do you have a USB cable?

○ Yes, I have a USB cable to use for installation.

○ No, I do not have a USB cable.
Note: If you do not have a USB cable you can still setup your device wirelessly (Advanced Method).

< Back   Next >   Cancel

[**Recommended**]
Temporarily use a USB cable for easy setup.

[Option]
Select if you do not have a USB cable.

Follow the on-screen instructions to continue the installation.

Finish

NOTE:
If connection is unsuccessful, repeat this step.

Configuration without using the CD-ROM (Windows® without CD-ROM drive or Macintosh)

Download the full driver and software package from the Brother Solutions Center.
(For Windows®) solutions.brother.com/windows
(For Macintosh) solutions.brother.com/mac

Print using your mobile device

Print from your mobile devices using our free application "Brother iPrint&Scan".

**1.** Connect the machine and wireless LAN access point/router from the machine's Touchscreen.

Press WiFi .

Press Setup Wizard.

Press Yes to enable WLAN.

Select the specified SSID, and then enter the Network key.

2. Download "Brother iPrint&Scan" to start using your machine with mobile devices.
solutions.brother.com/ips

Finish