brother

Read this Quick Setup Guide before using the printer. Before you can use the printer, you must set up the hardware and install the driver.

Step 1



page 20

page 22

Setting Up Your Printer

Windows[®] Parallel

Windows[®] Network

Installing the Driver

Macintosh[®] USB

Macintosh[®] Network

Administrators

Setup is Complete!

page 27

page 29

page 30

For the latest drivers and to find the best solution for your problem or question, access the Brother Solutions Center directly from the CD-ROM/Driver or go to http://solutions.brother.com Keep this Quick Setup Guide and the supplied CD-ROM in a convenient place for quick and easy reference at all times.

page 24

Step 2 **Installing the Driver** Macintosh[®] Windows® **USB Network USB Parallel Network** page 16 page 18 Mac OS® X Mac OS® X Peer-to-Network Mac OS® Mac OS® Peer (LPR / NetBIOS) Shared 10.1 / 10.2 8.6 - 9.210.1 / 10.2 8.6 - 9.2**Printer**

Safety Precautions

To Use the Printer Safely



Warning

Indicates warnings that must be observed to prevent possible personal injury.



Note

Indicates cautions that must be observed to use the printer properly or prevent damage to the printer.



Hint

Indicates notes and useful tips to remember when using the printer.



User's Guide

Network User's Guide


Indicates reference to the User's Guide or Network User's Guide which is on the CD-ROM we have supplied.



Warning



There are high voltage electrodes inside the printer. Before replacing internal parts, cleaning the printer or clearing a paper jam, make sure you have turned OFF the power switch and unplugged the AC power cord from the AC power outlet/socket.






Do not handle the plug or AC power cord with wet hands. This constitutes an electric shock hazard.






The fusing unit becomes extremely hot during operation. Wait until it has cooled down sufficiently before replacing consumable items.



The fusing unit is marked with a caution label. Please do NOT take off or damage the label.



This printer is heavy and weighs approximately 30.5 kg (67.3 lb). To prevent injuries when moving or lifting this printer, make sure to use at least two people.

Table of Contents

	Regulations	2
	IGetting Started	
<u> </u>	Carton Components Control Panel Supplied CD-ROM South Setting Up Your Printer	5
3	tep 1 Setting Up Your Printer	
	Install the Toner Cartridges Remove the tension release pins of the Fusing Unit Install the OPC Belt Cartridge Load Paper in the Paper Tray Print a Test Page Setting Your Language on the Control Panel	8 9 10 11
Si	tep 2 Installing the Driver	12
SMODIIIAA	For USB Interface Cable Users For Parallel Interface Cable Users For Network Interface Cable Users For Brother Peer-to-Peer Network Printer Users (LPR / NetBIOS) For Network Shared Printer Users	18 20 20
INGCIIICONII	For USB Interface Cable Users For Mac OS® 8.6 to 9.2 Users For Mac OS® X 10.1 / 10.2 Users For Network Interface Cable Users For Mac OS® 8.6 to 9.2 Users For Mac OS® X 10.1 / 10.2 Users	24 27 29
	I For Administrators	
	Installing BRAdmin Professional utility (Windows [®] users only) Web BRAdmin (Windows [®] Users Only) Setting your IP Address, Subnet Mask and Gateway using BRAdmin Professional utility (Windows [®] users only) Factory Default Setting Print Printer Settings Page	32 33 33
	I Other Information	
	Shipment of the PrinterOptions	34 35
	I Troubleshooting User's Guide Chapter 6	

4

Regulations

Federal Communications Commission (FCC) Declaration of Conformity (For USA)

Responsible Party: **Brother International Corporation**

100 Somerset Corporate Boulevard

P.O. Box 6911

Bridgewater, NJ 08807-0911 USA

Telephone: (908) 704-1700

declares, that the products

Laser Printer HL-2700CN Product name:

Model number: HL-2700 Product options:

complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Call the dealer, Brother Customer Service, or an experienced radio/TV technician for help.

Important

A shielded interface cable should be used to ensure compliance with the limits for a Class B digital device. Changes or modifications not expressly approved by Brother Industries, Ltd.

could void the user's authority to operate the equipment.

Industry Canada Compliance Statement (For Canada)

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Radio interference (220-240 volt model only)

This printer follows EN55022 (CISPR Publication 22)/Class B.

Before you use this product, make sure that you use a double-shielded interface cable with twisted-pair conductors and that it is marked "IEEE1284 compliant". The cable must not be more than 2.0 metres long.

brother.

"EC" Declaration of Conformity

Manufacture

Brother Industries Ltd 15-1, Naeshiro-cho, Mizuho-ku, Nagoya 467-8561, Japan

Herewith declare that:

Products description: Laser Printer HI -2700CN **Product Name:**

is in conformity with provisions of the Directives applied: Low Voltage Directive 73/23/EEC (as amended by 93/68/EEC) and the Electromagnetic Compatibility Directive 89/336/EEC (as amended by 91/263/EEC and 92/ 31/EEC and 93/68/EEC).

Standards applied:

Harmonized:

Safety: EN60950: 2000

EMC: EN55022: 1998 + A1:2000 Class B

EN55024: 1998

EN61000-3-2: 1995 + A14:2000

EN61000-3-3: 1995

Year in which CE marking was First affixed: 2003

Issued by: Brother Industries, Ltd. Date: 15th May, 2003 Place: Nagoya, Japan Signature:

Japash Mareda

Manager

Quality Management Group Quality Management Dept. Information & Document Company

International Energy Star® Compliance Statement

The purpose of the International ENERGY STAR® Program is to promote the development and popularization of energy-efficient office equipments. As an ENERGY STAR® Partner, Brother Industries, Ltd. has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.



Laser Safety (100 to 120 volt Model Only)

This printer is certified as a Class I laser product under the U.S. Department of Health and Human Services (DHHS) Radiation Performance Standard according to the Radiation Control for Health and Safety Act of 1968. This means that the printer does not produce hazardous laser radiation.

Since radiation emitted inside the printer is completely confined within protective housings and external covers, the laser beam cannot escape from the machine during any phase of user operation.

FDA Regulations (100 to 120 volt Model Only)

U.S. Food and Drug Administration (FDA) has implemented regulations for laser products manufactured on and after August 2, 1976. Compliance is mandatory for products marketed in the United States. One of the following labels on the back of the printer indicates compliance with the FDA regulations and must be attached to laser products marketed in the United States.

MANUFACTURED:

Brother Industries, Ltd.,

15-1 Naeshiro-cho Mizuho-ku Nagoya, 467-8561 Japan

This product complies with FDA radiation performance standards, 21 CFR subchapter J.

Caution:

Use of controls, adjustments or performance of procedures other than those specified in this manual may result in hazardous radiation exposure

IEC 60825 specification (220 to 240 volt model only)

This printer is a Class 1 laser product as defined in IEC 60825 specifications. The label shown below is attached in countries where it is needed.



This printer has a Class 3B laser diode which produces invisible laser radiation in the scanner unit. You should not open the scanner unit under any circumstances.

Caution:

Use of controls or adjustments or performance of procedures other than those specified in this User's Guide may result in hazardous radiation exposure.

For Finland and Sweden LUOKAN 1 LASERLAITE KLASS 1 LASER APPARAT

Varoitus!

Laitteen käyttäminen muulla kuin tässä käyttöohjeessa mainitulla tavalla saattaa altistaa käyttäjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteiivlle.

iasersatellylle

▼ Varning Om apparaten används på annat sätt än i denna

Bruksanvisning specificerats, kan användaren utsättas för osynlig laserstrålning, som överskrider gränsen för

laserklass 1.

Internal laser radiation

Maximum radiation power: 5 mW
Wave length: 780 - 800 nm
Laser class: Class IIIb

(Accordance with 21 CFR Part 1040.10)

Class 3B

(Accordance with IEC 60825)

IMPORTANT - For Your Safety

To ensure safe operation the supplied three-pin plug must be inserted only into a standard three-pin power outlet that is properly grounded through the normal household wiring.

Extension cords used with this printer must be three-pin plug type and correctly wired to provide proper grounding. Incorrectly wired extension cords may cause personal injury and equipment damage.

The fact that the equipment operates satisfactorily does not imply that the power is grounded and that the installation is completely safe. For your safety, if in any doubt about the effective grounding of the power, call a qualified electrician.

Disconnect device

You must install this printer near a power outlet that is easily accessible. In case of an emergency, you must disconnect the power cord from the power outlet to shut off the power completely.

Caution for LAN connection

Connect this product to a LAN connection that is not subjected to over voltages.

IT power system (For Norway only)

This product is also designed for an IT power system with phase-to-phase voltage 230V.

Geräuschemission / Acoustic noise emission (for Germany only)

Lpa < 70 dB (A) DIN 45635-19-01-KL2

Wiring information (for UK)

Important

If you need to replace the plug fuse, fit a fuse that is approved by ASTA to BS1362 with the same rating as the original fuse.

Always replace the fuse cover. Never use a plug that does not have a cover.

Warning - This printer must be earthed.


The wires in the mains lead are coloured in line with the following code:

Green and Yellow: Earth
Blue: Neutral
Brown: Live

If in any doubt, call a qualified electrician.

■ Getting Started

Carton Components



Carton components may differ from one country to another.

The power cord may be slightly different to the one in the diagram above, depending upon which country you bought the printer in.


Save all packing materials and the printer carton.




- The interface cable is not a standard accessory. Buy the appropriate interface cable for the interface vou intend to use (Parallel, USB or Network).
- It's recommended to use a parallel or USB interface cable that is not longer than 6 feet (2.0 meters).
- For a parallel interface cable users, use a shielded interface cable that is IEEE 1284-compliant.
- Use a Hi-Speed USB 2.0 certified cable if your computer uses a Hi-Speed USB 2.0 interface.
- ^{*1} The toner cartridges that come supplied with this printer, are starter toners. Starter toners, are toner cartridges with up to half the life of the standard toner cartridge, 5000 pages (Black) and 3000 pages (Cyan, Magenta and Yellow) at approximately 5% print coverage (A4 or Letter size).


 *2 Repacking kit is to be used ONLY for moving or shipping the printer.
- *3 We recommend that you put the parts/paper jam locator label onto the top left hand side of the printer.

The meanings of icons on the parts/paper jam locator label are shown below.





Control Panel





User's Guide Chapter 3.

Buttons

1 Job Cancel Button

Stop and cancel the printer operation that is in progress.

2 Menu Buttons		
+	Move forward through menus.	
 Move backward through menus. 		
Set	Select the control panel. Set the selected menus and settings.	
Back	Go back one level in the menu structure.	

3 Go Button

Exit from the control panel menu, reprint settings, clear error messages and sleep mode.

Pause / continue printing

LEDs


4 Status LED : Green		
On	Ready to print Printing Sleeping Data remains in the printer buffer (when DATA EXISTS is shown on the LCD).	
Blinking	Receiving or processing data	
Off	The printer power is off. The printer is off-line.	
5 Alarm L	.ED: Red	
On	There is an error in the printer.	
Off	There is no error in the printer.	

■ Getting Started


Supplied CD-ROM

You can find a variety of information on the CD-ROM.

Windows®



Macintosh[®]



This screen is not supported by Mac OS® 8.6 to 9.2.

1 Brother Solutions Center

The Brother Solutions Center (http://solutions.brother.com) is a one-stop resource for all your printer needs. Download the latest drivers and utilities for your printers, read the FAQs and troubleshooting tips, or learn about printer solutions.

2 Install Software

Installs the printer driver and utilities.

3 Documentation

View the printer's User's Guide and Network User's Guide in PDF format. (Viewer included)

4 Maintenance Tutorial

Instructional movie for printer maintenance.

5 On-Line Registration

Register your product on-line.

6 Color PDF Print Samples

View and print color PDF samples that where printed on a HL-2700CN.



For visually impaired users:

Please see a HTML file, readme.html, on the supplied CD-ROM. You can read it with Screen Reader 'text-to-speech' software.

Step 1


Setting Up Your Printer



1 Install the Toner Cartridges

0


Do NOT connect the interface cable. You will be prompted to connect the interface cable during the driver installation.




0

Do NOT touch the green surface of the OPC belt or expose it to direct sunlight or room light for any length of time.


Remove the protective parts.




2 Open the front cover.




3 Remove the protective part.




4 Take out all the toner cartridges from the printer.



Carefully pull the red protective paper out of the printer.



6 Rock the toner cartridge 3 to 4 times.



Go to the next page

Setting U

Windows USB

Windows[®] Parallel

Windows[®] Network

Installing the Driver

lacintosh[®]


Macintosh[®] Network

For Administrators


Step 1

Setting Up Your Printer


7 Pull off the tape labeled REMOVE, and then remove the orange protective cover.




8 Put the toner cartridge by sliding it into the correct guide. Match the cartridge color label to the corresponding label on the printer.



9 Repeat steps 5 through 7 for the remaining toner cartridges.




10 Close the front cover.




Remove the tension release pins of the Fusing Unit


1 Open the back cover.



2 Pull out the tension release pins from both sides of the fusing unit.




3 Close the back cover.




Installing the Driver

Install the OPC Belt Cartridge


1 Open the top cover.




Remove the orange belt tension release pins from both sides of the OPC belt cartridge. Remove the protective sheet.



3 Put the OPC belt cartridge into the printer guides with the flat side facing you.



4 Lock the belt cartridge lock levers. Close the top cover.




Go to the next page


Setting Up Your Printer

4 Load Paper in the Paper Tray


1 Pull the paper tray completely out of the printer.




While pressing the paper guide release lever, slide the adjusters to fit the paper size. Check that the guides are firmly in the slots.




3 Fan the stack of paper well to avoid paper jams and misfeeds.



4 Put paper in the paper tray.
Check that the paper is flat in the tray and below the maximum paper mark.



5 Put the paper tray firmly back in the printer.




Installing the Driver

Print a Test Page




Do NOT connect the interface cable. Connecting the interface cable is done when installing the driver.



1 Make sure that the printer's power switch is

Connect the AC power cord to the printer.



2 Plug the AC power cord into an AC power outlet/socket.

Turn the printer's power switch on.





3 After the printer has finished warming up, the READY message appears.



Press the Go button. The printer prints a test page.
Check that the test page has printed correctly.



Go to the next page

Step 1 Setting Up Your Printer

Setting Your Language on the Control Panel



1 Press the + button until SETUP is displayed. Press the **Set** button.

```
-- MENU --
SETUP
```

Press the Set button again.

```
SETUP
LANGUAGE
```

3 Press the + or - button to select your language. Press the **Set** button to accept.

```
LANGUAGE
=ENGLISH
               *
```

Go to the next page to install the driver.

Step 2

Installing the Driver



Follow the instructions on this page for your operating system and interface cable. The screens for Windows $^{\text{@}}$ in this Quick Setup Guide are based on Windows $^{\text{@}}$ XP. The screens for Mac OS $^{\text{@}}$ X in this Quick Setup Guide are based on Mac OS $^{\text{@}}$ X 10.1.

Setting Up

ws_®

Vindows[®] Parallel

> Windows[©] Network

∕acintosh[®] USB

Macintosh Network

	For USB Interface Cable Users Go to	page 14
Windows®	For Parallel Interface Cable Users Go to	page 16
>	For Network Interface Cable Users Brother Peer-to-Peer Network Printer Users (LPR / NetBIOS)	
)sh [®]	For USB Interface Cable Users Mac OS® 8.6 to 9.2 Users	page 24 page 27
Macintosh®	For Network Interface Users Mac OS® 8.6 to 9.2 Users	

For Administrators Go to page 32



For USB Interface Cable Users


1. Installing the Driver and Connecting the Printer to your PC



If the Found New Hardware Wizard appears on your PC, click the Cancel button.



Make sure the USB interface cable is NOT connected to the printer, and then begin installing the driver. If you have already connected the cable, remove it.



2 Insert the CD-ROM into your CD-ROM drive. The opening screen will appear automatically.

Follow the on-screen instructions.




Click Install Software icon on the menu screen.




Click **Printer Driver**.



Click the **Next** button. Follow the on-screen instructions.



Select Standard Installation, and then click the Next button.






If you want to install the PS driver, select Custom and then follow the on-screen instructions. When the Select Components screen appears, check PS Printer Driver, and then continue following the on-screen instructions.

7 Select Local Printer with USB cable, and then click the Next button.



8 When this screen appears, make sure the printer's power switch is on.
Connect the USB interface cable to your PC, and then connect it to the printer.
Click the **Next** button.





9 Click the **Finish** button.





If you want to register your product on-line, check **On-Line Registration**.

- For Windows[®] 98 / Me users: Setup is now complete.
- For Windows® 2000/XP users:
 Go to "2. Setting your Printer as the Default Printer".

- 2. Setting your Printer as the Default Printer (For Windows® 2000/XP Users Only)
- 1 Click Start and then Printers and Faxes.



Select the Brother HL-2700CN series icon.



3 From the File menu, select Set as Default printer.




OK! Setup is now complete.




For Parallel Interface Cable Users

Connecting the Printer to your PC and Installing the Driver


1 Turn off the printer's power switch.



2 Connect the parallel interface cable to your PC, and then connect it to your printer.



Turn on the printer's power switch.





If the Found New Hardware Wizard appears on your PC, click the Cancel button.



Insert the CD-ROM into your CD-ROM drive. The opening screen will appear automatically.

Follow the on-screen instructions.



Click Install Software icon on the menu screen.



Click Printer Driver.



Click the **Next** button. Follow the on-screen instructions.



Installing the Driver

8 Select **Standard Installation**, and then click the **Next** button.






If you want to install the PS driver, select **Custom** and then follow the on-screen instructions. When the **Select Components** screen appears, check **PS Printer Driver**, and then continue following the on-screen instructions.


Select Local Printer, and then click the Next button.



10 Select the port that your printer is connected to, and then click the **Next** button.



11 Click the Finish button.





If you want to register your product on-line, check **On-Line Registration**.

OK! Setup is now complete.



For Network Interface Cable Users


For Brother Peer-to-Peer Network Printer Users (LPR / NetBIOS)




- If you are going to connect the printer to your network, we recommended that you contact your system administrator prior to installation.
- Before installation, if you are using Personal Firewall software (e.g. the Internet Connection Firewall available in Windows XP), disable it. Once you are sure that you can print, re-start your Personal Firewall software.

Connecting the Printer to your Network and Installing the Driver


Turn off the printer's power switch.



Connect the network interface cable to the printer, and then connect it to a free port on your hub.



Turn on the printer's power switch.



Insert the CD-ROM into your CD-ROM drive. The opening screen will appear automatically.

Follow the on-screen instructions.



5 Click Install Software on the menu screen.




Click Printer Driver.



Click the Next button. Follow the on-screen instructions.



8 Select **Standard Installation**, and then click the **Next** button.





If you want to install the PS driver, select **Custom** and then follow the on-screen instructions. When the **Select Components** screen appears, check **PS Printer Driver**, and then continue following the on-screen instructions.

Select Brother Peer-to-Peer Network Printer, and then click the Next button.




10 For LPR Users:

Select Search the network for devices and choose from a list of discovered divices (Recommended). Or enter your printer's IP address or its node name. Click the **Next** button.

For NetBIOS Users:

Select Search the network for devices and choose from a list of discovered devices (Recommended).

Click the Next button.





Contact your Administrator about the printer's IP Address or node name.


11 For LPR Users:

Select your printer and LPR (Recommended), and then click the Next button.



For NetBIOS Users:

Select your printer and **NetBIOS**, and then click the **Next** button.



12 Click the Finish button.





If you want to register your product on-line, check **On-Line Registration**.



For Windows[®] 95 / 98 / Me users:
After your PC has restarted, setup will be complete.



For Network Interface Cable Users


For Network Shared Printer Users




If you are going to connect the printer to your network, we recommended that you contact your system administrator prior to installation.

Installing the Driver, Connecting the Cable and Selecting the Appropriate **Printer Queue or Share name**


Turn off the printer's power switch.



Connect the network interface cable to the printer, and then connect it to a free port on your hub.



Turn on the printer's power switch.



Insert the CD-ROM into your CD-ROM drive. The opening screen will appear automatically.

Follow the on-screen instructions.




Click Install Software on the menu screen.



Click Printer Driver.



Click the Next button. Follow the on-screen instructions.



Installing the Driver

8 Select **Standard Installation**, and then click the **Next** button.





If you want to install the PS driver, select **Custom** and then follow the on-screen instructions. When the **Select Components** screen appears, check **PS Printer Driver**, and then continue following the on-screen instructions.

Select the Network Shared Printer, and then click the Next button.



10 Select your printer's queue, and then click the **OK** button.





Contact your Administrator about the printer's queue.

11 Click the Finish button.





If you want to register your product on-line, check **On-Line Registration**.



Setup is now complete.




For USB Interface Cable Users

For Mac OS® 8.6 to 9.2 Users

Connecting the Printer to your Macintosh® & Installing the Driver


Make sure the printer's power switch is on.



Connect the USB interface cable to your Macintosh®, and then connect it to the printer.




Do not connect the USB cable to the keyboard USB Port or a non-powered USB Hub.




Insert the CD-ROM into your CD-ROM drive.

Open the Mac OS 9 folder.



Open your language folder.




Double-click the **BR-Script PPD installer**

Follow the on-screen instructions.




Open the Macintosh HD icon.




7 For Mac OS[®] 8.6 to 9.04 Users:
Open the Apple Extras folder.
Open the Apple LaserWriter Software folder.


For Mac OS[®] 9.1 to 9.2 Users: Open the **Applications** (Mac OS[®] 9) folder. Open the **Utilities** folder.




- * The screens are based on Mac OS® 9.04.
- 8 Open the **Desktop Printer Utility** icon.




Select Printer (USB), and then click the OK button.




Olick the Change... button in PostScriptTM Printer Description (PPD) File.
Select Brother HL-2700CN series, and then click the Select button.



Click the Change... button in the USB Printer Selection.
Select HL-2700CN series, and then click the OK button.



Click the Create... button.




Continue to the next page



For USB Interface Cable Users

13 Enter your printer name (HL-2700CN series), and then click the Save button.



14 Select Quit from the File menu.



15 Click the **HL-2700CN series** icon on the Desktop.



16 From the **Printing** menu, select **Set Default** Printer.



Setup is now complete.




For USB Interface Cable Users

For Mac OS® X 10.1 / 10.2 Users

Connecting the Printer to your Macintosh® & Installing the BR-Script PPD File


Make sure the printer's power switch is on.



Connect the USB interface cable to your Macintosh®, and then connect it to the printer.



Do not connect the USB cable to the keyboard USB Port or to a non-powered USB Hub.



Insert the CD-ROM into your CD-ROM drive.


Double click the Start Here OS X icon. Follow the instructions on the screen.




Click Install Software on the menu screen. Follow the on-screen instructions.



From the **Go** menu, select **Applications**.



Open the **Utilities** folder.



Open the Print Center icon.




Continue to the next page



For USB Interface Cable Users


8 Click the Add Printer... button.



9 Select USB.



10 Select **HL-2700CN series**, and then click the Add button.



from the **Print Center** menu, select **Quit** Print Center.



Setup is now complete.

For Network Interface Cable Users


For Mac OS[®] 8.6 to 9.2 Users

Connecting the Printer to your Macintosh® & Installing the BR-Script PPD File

1 Turn off the printer's power switch.



Connect the network interface cable to the printer, and then connect it to a free port on your hub.




3 Turn on the printer's power switch.



Insert the CD-ROM for Macintosh® into your CD-ROM drive.
Open the **Mac OS 9** folder.

Open your language folder.




5 Double-click the **BR-Script PPD Installer** icon to install the PPD file.
Follow the on-screen instructions.



6 From the Apple menu, open the Chooser.



7 Click the **LaserWriter 8** *1 icon, and then select **BRN_xxxxxx_P1_AT**. *2 Click the **Create** button. Close the **Chooser**.



- *1 If the Apple LaserWriter 8 Driver is not already installed on your system, you can download it from http://www.apple.com
- *2 xxxxxx are the last six digits of the Ethernet address.



Network User's Guide Chapter 7.

Setup is now complete.




For Network Interface Cable Users


For Mac OS® X 10.1 / 10.2 Users

Connecting the Printer to your Macintosh® & Installing the BR-Script PPD File


Turn off the printer's power switch.



Connect the network interface cable to the printer, and then connect it to a free port on your hub.



Turn on the printer's power switch.




4 Insert the CD-ROM into the CD-ROM drive. Double click the Start Here OS X icon. Follow the instructions on the screen.




Click Install Software on the menu screen. Follow the on-screen instructions.



From the **Go** menu, select **Applications**.



Open the **Utilities** folder.




8 Open the **Print Center** icon.



For Network Interface Cable Users

9 Click the **Add Printer...** button.



Select AppleTalk.



11 Select BRN_xxxxxx_P1_AT*1, and then click the Add button.



*1 xxxxxx are the last six digits of the Ethernet address.



Network User's Guide Chapter 7.

12 From the Print Center menu, select Quit **Print Center.**





Setup is now complete.

■ For Administrators

Installing BRAdmin Professional utility (Windows® users only)

The BRAdmin Professional utility is designed to manage your Brother network-connected devices.

BRAdmin Professional utility can also be used to manage devices from other manufacturers whose products support SNMP (Simple Network Management Protocol).

For more information on BRAdmin Professional go to http://solutions.brother.com

1 Insert the CD-ROM into your CD-ROM drive. The opening screen will appear automatically.

Follow the on-screen instructions.



Click the Install Software icon on the menu screen.



Click For Administrators.



4 Click BRAdmin Professional.





The default password for the print server is 'access'. You can use the BRAdmin Professional utility or a web browser to change this password.

Web BRAdmin (Windows® Users Only)

Brother has also developed Web BRAdmin, an enterprise network software utility that enables the management of Brother and other SNMP-compliant devices in larger LAN/WAN environments.


This software is Web server based and requires the installation of Microsoft's Internet Information Server and Sun's Java client software. To learn more about the Web BRAdmin software or to download it, please go to http://solutions.brother.com/webbradmin

Setting Up

Installing the Driver


Setting your IP Address, Subnet Mask and Gateway using BRAdmin Professional utility (Windows® users only)

1 Start BRAdmin Professional, and select TCP/IP.



Select Search Active Devices from the Devices menu.

BRAdmin will search for new devices automatically.



3 Double-click the new device.




4 Enter the IP Address, Subnet Mask and Gateway, and then click the OK button.



5 The address information will be saved to the printer.

Print Printer Settings Page

The Printer Settings Page lists all the current printer settings, including network settings. To print the Printer Settings Page, press the **Set** button three times.



Factory Default Setting

You can reset all the print server settings (including the password) back to factory defaults. For steps on how to reset the print server, see Chapter 3 "Network factory default setting" on page 3-22 of the User's Guide.



User's Guide Chapter 3

■ Other Information

Shipment of the Printer



Once your printer has been set-up and used, we do not recommend that it be moved or shipped unless absolutely necessary.

Color laser printers are complex printing devices. Moving the printer or shipping it without properly removing the installed supplies can result in SEVERE damage to the printer. As a result, your printer may not operate properly afterwards.

If the printer must be shipped, please go to http://solutions.brother.com for a detailed, step-by-step instruction on how to properly prepare your printer for transport.

Failure to properly prepare the printer for shipping according to the instructions located at http://solutions.brother.com may VOID YOUR WARRANTY.

Trademarks

The Brother logo is a registered trademark of Brother Industries, Ltd.

Windows® and Windows NT® are registered trademarks of Microsoft Corporation in the U.S and other countries.

Apple Macintosh®, iMac, LaserWriter, and AppleTalk are trademarks of Apple Computer, Inc.

HP, HP/UX, JetDirect and JetAdmin are trademarks of Hewlett-Packard Company.

UNIX is a trademark of UNIX Systems Laboratories.

Adobe PostScript[®] and PostScript3TM are trademarks of Adobe Systems Incorporated.

Netware is a trademark of Novell, Inc.

ENERGY STAR is a U.S. registered mark.

All other brand and product names mentioned in this Quick Setup Guide are registered

Compilation and Publication

This manual has been compiled and published under the supervision of Brother Industries Ltd., covering the latest product descriptions and specifications.

The contents of this manual and the specifications of this product are subject to change without notice.

Brother reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication.

This product is designed for use in a professional environment.

This printer contains UFST and Micro Type from Monotype Imaging Inc.

Options

The printer has the following optional accessories. You can expand the capabilities of the printer by adding these items.



User's Guide Chapter 4.

Lower Tray Unit	Legal Tray	Duplex Unit
LT-27CL	LT-27LG	DX-2700
Second lower paper tray unit expands total input capacity up to 530 sheets.	You can print on legal sized paper as well as A4, B5 and others.	The Duplex unit is an optional device that allows you to print on both sides of a page.

CompactFlash Card	SO-DIMM Memory	Font Package
		BS-3000
The printer accepts a CompactFlash card for saving macros, print jobs, fonts and print logs.	You can expand the memory up to a total of 576 MB by installing (144-pin SO-DIMM) memory modules.	The optional font package (BS-3000) is the CD-ROM you need for installing the 136 PS3 Agfa and TrueType Fonts.

Barcode Font
BT-1000
0
The optional Barcode fonts package (BT-1000) is the CD-ROM you need for installing the Barcode Fonts.

