Quick Setup Guide

DCP-750CW



Before you can use the machine, you must set up the hardware and install the software.
Please read this Quick Setup Guide for the correct setup procedure and installation instructions.

STEP 1
Setting Up the Machine

STEP 2
Installing the Driver & Software

Setup is Complete!

Keep this Quick Setup Guide, the User's Guide and the supplied CD-ROM in a convenient place for quick and easy reference at all times.

Version A

Symbols used in this guide

Warning	Caution	Improper Setup
Warnings tell you what to do to prevent possible personal injury.	Cautions specify procedures you must follow or avoid to prevent possible damage to the machine or other objects.	Improper Setup icons alert you to devices and operations that are not compatible with the machine.
Note	User's Guide, Software User's Guide or Network User's Guide	
Notes tell you how you should respond to a situation that may arise or give tips about how the current operation works with other features.	Indicates reference to the User's Guide, Software User's Guide or Network User's Guide we have supplied.	

Table of Contents

Getting Started

Carton components 2
Control panel 3

STEP1 – Setting Up the Machine

Removing the protective parts 4
Loading paper 4
Connecting the power cord 6
Choosing your language 6
Installing the ink cartridges 7
Print quality check 9
Setting the LCD Contrast 10
Setting the date and time 10

STEP2 – Installing the Driver & Software

Windows®

For USB Interface Users
(For Windows® 98/98SE/Me/2000 Professional/XP/XP Professional x64 Edition) 14
For Wired Network Interface Users
(For Windows® 98/98SE/Me/2000 Professional/XP/XP Professional x64 Edition) 17
For Wireless Network Users
(For Windows® 98/98SE/Me/2000 Professional/XP/XP Professional x64 Edition
in infrastructure mode) 21

Macintosh®

For USB Interface Users
(For Mac OS® X 10.2.4 or greater) 30
For Wired Network Interface Users
(For Mac OS® X 10.2.4 or greater) 33
For Wireless Network Users
(For Mac OS® X 10.2.4 or greater in infrastructure mode) 36

For Network Users

BRAdmin Professional configuration utility (For Windows® users) 43
Installing the BRAdmin Professional configuration utility 43
Setting your IP address, Subnet Mask and Gateway using BRAdmin Professional 43
BRAdmin Light configuration utility (For Mac OS® X users) 44
Setting your IP address, Subnet Mask and Gateway using BRAdmin Light 44
How to set the machine's network settings to wireless LAN or wired LAN 45
Restoring the network settings to factory default 45
Entering Text 46

Consumables

Replacement consumables 47
Ink cartridge 47

Carton components

Carton components may vary from one country to another.
Save all packing materials and the carton in case for any reason you must ship your machine.



 **Quick Setup Guide**	**CD-ROM**	 **User's Guide**	**Power Cord**
 **Black** (LC1000BK)	 **Yellow** (LC1000Y)	 **Cyan** (LC1000C)	 **Magenta** (LC1000M)
Ink Cartridges			

An interface cable is not a standard accessory. You need to purchase an appropriate USB 2.0 interface cable or network cable.

USB cable

- Please make sure you use a USB 2.0 cable that is no longer than 2 metres long (6 feet).
- Your machine has a USB interface that is compatible with the USB 2.0 specification.
- DO NOT connect the interface cable at this time.
  Connecting the interface cable is done during the software installation process.

Network cable

- Use a straight-through Category5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.

Control panel



1 Number of Copies key
2 Menu keys
3 Start keys
4 Stop/Exit key
5 On/Off key
6 Ink Management key
7 Scan key
8 PhotoCapture key
9 Warning LED
10 LCD (Liquid Crystal Display)

For the details of the control panel, see Control panel overview in Chapter 1 of the User's Guide.

1 Removing the protective parts

1 Remove the protective tape and film covering the scanner glass.

2 Remove the foam bag containing the ink cartridges from on top of the paper tray.

Improper Setup

DO NOT connect the interface cable. Connecting the interface cable is done during the software installation process.



2 Loading paper

You can load up to 100 sheets of 80 g/m^2 (20 lb) paper.
For details, see Acceptable paper and other media in Chapter 2 of the User's Guide.

1 Pull the paper tray completely out of the machine and lift the output paper tray cover (1).





2 Press and slide the paper side guides (1) and paper length guide (2) to fit the paper size.



3 Fan the stack of paper well to avoid paper jams and misfeeds.



4 Gently put the paper into the paper tray print side down and top edge first.
Check that the paper is flat in the tray.



5 Gently adjust the paper side guides with both hands to fit the paper. Make sure that the paper guides touch the edges of the paper.



Note

Be careful that you do not push the paper in too far; it may lift at the back of the tray and cause paper feed problems.

6 Close the output paper tray cover.



7 Slowly push the paper tray completely into the machine.



8 While holding the paper tray in place, pull out the paper support (①) until it clicks, and then unfold the paper support flap (②).



Note

Do not use the paper support flap for Legal paper.

Note

You can use the photo paper tray which is located on the top of the paper tray to print on photo 10 × 15 cm (4 × 6 in.) and photo L size paper. For details, see Loading envelopes, post cards and photo paper in Chapter 2 of the User's Guide.

3 Connecting the power cord

1 Connect the power cord.



Improper Setup

DO NOT connect the interface cable. Connecting the interface cable is done during the software installation process.

Warning

The machine must be fitted with an earthed plug.

Note

The control panel warning LED will stay on until you have installed the ink cartridges.

4 Choosing your language

1 After connecting the power cord, the LCD shows:

```
Select Language
English
Français
Deutsch
Nederlands
Italiano
```

Press ▲ or ▼ to choose your language and press **OK**.

2 Choose Yes or No and press **OK**.

```
English
Yes
No
```

3 If your language is chosen, press **OK**.

If you set the wrong language, you can change the language after setting the date and time. (For details, see changing LCD language in Appendix B of the User's Guide.)

5 Installing the ink cartridges

Warning

If ink gets in your eyes, wash them out with water at once, and if irritation occurs consult a doctor.

1 Make sure that the power is turned on.
The LCD shows:

```
No Cartridge
Black
Yellow
Cyan
Magenta
```

2 Open the ink cartridge cover (1).



3 Pull all the lock release levers down and remove the yellow protective part (1).



Note

Do not throw away the yellow protective part. You will need it if you transport the machine.

4 Take out the ink cartridge.



5 Carefully remove the protective yellow cap (1).



Improper Setup

DO NOT touch the area shown in the illustration below.



Note

If the protective yellow cap comes off when you open the bag, the cartridge will not be damaged.

6 Install each ink cartridge in the direction of the arrow on the label.
Take care to match the colour of the lock release lever (1) with the cartridge colour (2), as shown in the diagram below.





7 Lift each lock release lever and gently push it until it clicks, and then close the ink cartridge cover.



Note

If the LCD prompts you to re-insert the ink cartridge correctly, after you install the ink cartridges, check that the ink cartridges are installed correctly.

The machine will clean the ink tube system for use for the first time. This process will occur only once, the first time ink cartridges are installed. The cleaning process will last approximately four minutes.
The LCD shows:

```
Cleaning
→ → → → →

Preparing System
Approx 4 Minutes
```

Caution

- **DO NOT take out ink cartridges if you do not need to replace them. If you do so, it may reduce the ink quantity and the machine will not know the quantity of ink left in the cartridge.**
- **DO NOT shake the ink cartridges. If ink stains your skin or clothing, wash with soap or detergent at once.**
- **DO NOT repeatedly insert and remove the cartridges. If you do so, ink may seep out of the cartridge.**
- **If you mix the colours by installing an ink cartridge in the wrong position, clean the print head several times after correcting the cartridge installation. (See *Cleaning the print head in Appendix B of the User's Guide*.)**
- **Once you open an ink cartridge, install it in the machine and use it up within six months of installation. Use unopened ink cartridges by the expiration date written on the cartridge package.**
- **DO NOT dismantle or tamper with the ink cartridge, this can cause the ink to leak out of the cartridge.**
- **Brother multifunction machines are designed to work with ink of a particular specification and will work to a level of optimum performance when used with genuine Brother branded ink cartridges.**
  Brother cannot guarantee this optimum performance if ink or ink cartridges of other specifications are used. Brother does not therefore recommend the use of cartridges other than genuine Brother branded cartridges with this machine or the refilling of empty cartridges with ink from other sources. If damage is caused to the print head or other parts of this machine as a result of using incompatible products with this machine, any repairs required as a result may not be covered by the warranty.

6 Print quality check

1 After the cleaning cycle is finished, the LCD shows:



2 Make sure paper is loaded in the paper tray. Press **Colour Start**.
The machine starts printing the Print Quality Check Sheet (only during initial ink cartridge installation).

3 Check the quality of the four colour blocks on the sheet.
(black/yellow/cyan/magenta)



Improper Setup

Avoid touching the printed surface of the paper immediately after printing, the surface may not be completely dry and may stain your fingers.

4 The LCD shows:



5 Do one of the following:

- If all lines are clear and visible, press + (Yes) to finish the quality check.
- If you can see missing short lines, press - (No) and go to step **6**.

OK



Poor



6 The LCD asks you if the print quality is OK for black and colour. Press + (Yes) or - (No).





After pressing + (Yes) or - (No) for both black and colour, the LCD shows:



7 Press + (Yes), the machine will then start cleaning the colours.

8 After cleaning is finished, press **Colour Start**. The machine starts printing the Print Quality Check Sheet again and goes back to step **3**.

7 Setting the LCD Contrast

You can adjust the LCD contrast for a sharper and more vivid display. If you are having difficulty reading the LCD, try changing the contrast setting.

1. Press **Menu**.
2. Press ▲ or ▼ to choose `General Setup`. Press **OK**.
3. Press ▲ or ▼ to choose `LCD Settings`. Press **OK**.
4. Press ▲ or ▼ to choose `LCD Contrast`. Press **OK**.
5. Press ▲ or ▼ to choose `Light`, `Med` or `Dark`. Press **OK**.
6. Press **Stop/Exit**.

Note

You can also adjust the angle of the LCD display by lifting it.

8 Setting the date and time

Setting the date and time allows the machine to clean the print head regularly and maintain optimum print quality. It also allows the machine to name files created when using the Scan to Card feature.

1. Press **Menu**.
2. Press ▲ or ▼ to choose `Initial Setup`, and then press **OK**.
3. Press ▲ or ▼ to choose `Date/Time`, and then press **OK**.
4. Press ▲ repeatedly to enter the last two digits of the year, and then press **OK**.



(e.g. Enter **0 7** for 2007.)

5. Press ▲ repeatedly to enter the two digits for the month, and then press **OK**.



(e.g. Enter **0 1** for January.)

6. Press ▲ repeatedly to enter the two digits for the day, and then press **OK**.



(e.g. Enter **0 1** for the first day of the month.)

7 Press ▲ repeatedly to enter the two digits for the hour in 24-hour format, and then press ▶ to next.



(e.g. Enter **1** **5** for 3:00 P.M.)

8 Press ▲ repeatedly to enter the two digits for the minutes, and then press **OK**.



(e.g. Enter **1** **5**, **2** **5** for 3:25 P.M.)

Note

You can increase or decrease the number rapidly by holding down ▲ or ▼.

9 Press **Stop/Exit**.

Note

*If you want to start again, press **Stop/Exit** to go back to step **1**.*

To confirm the current date and time, print out the Users Settings Report. (See Printing Reports in Chapter 1 of the User's Guide.)

Now go to

Go to *Supplied CD-ROM 'MFL-Pro Suite'* on the next page to install the drivers.

Supplied CD-ROM ‘MFL-Pro Suite’

Windows®



Install MFL-Pro Suite

You can install the MFL-Pro Suite software and multifunction drivers.

Install Other Drivers or Utilities

You can install additional MFL-Pro Suite software utilities, install without PaperPort® SE, or install the printer driver only.

User’s Guide

View the Software User’s Guide and Network User’s Guide in HTML format. The Software User’s Guide and Network User’s Guide include instructions for features available when connected to a computer. (eg. Printing, scanning and networking details)

On-Line Registration

You will be pointed to the Brother Product Registration Web page for quick registration of your machine.

Brother Solutions Center

You can access the Brother Solutions Center which is a Web site offering information about your Brother product including FAQs, User’s Guides, driver updates and tips for using your machine.

Repair MFL-Pro Suite (USB only)

If an error occurred during the installation of the MFL-Pro Suite, use this selection to automatically repair and re-install the MFL-Pro Suite.

Note

MFL-Pro Suite includes the Printer Driver, Scanner Driver, Brother ControlCenter3, ScanSoft® PaperPort® SE with OCR and True Type® fonts.

PaperPort® SE is a document management application for scanning and viewing documents.

Macintosh®

Start Here OSX

You can install the MFL-Pro Suite that includes the printer driver, scanner driver and the Brother ControlCenter2 for Mac OS® 10.2.4 or greater.

Presto! PageManager

You can also install Presto!® PageManager® to add OCR capability to the Brother ControlCenter2 and easily scan, share and organize photos and documents.

Documentation

View the Software User’s Guide and Network User’s Guide in HTML format. The Software User’s Guide and Network User’s Guide include instructions for features available when connected to a computer. (eg. Printing, scanning and networking details)

Brother Solutions Center

You can access the Brother Solutions Center which is a Web site offering information about your Brother product including FAQs, User’s Guides, driver updates and tips for using your machine.

On-Line Registration

You will be pointed to the Brother Product Registration Web Page for quick registration of your machine.

Utilities

You can use the following additional Utilities in this folder.

- **Wireless LAN Setup Wizard**
- **Presto!® PageManager® UnInstaller**
- **BRAdmin Light**

STEP 2 Installing the Driver & Software

Follow the instructions on this page for your operating system and interface.
For the latest drivers and documentations and to find the best solution for your problem or question, access the Brother Solutions Center directly from the driver or visit http://solutions.brother.com.

Windows®

For USB Interface Users
(For Windows® 98/98SE/Me/2000 Professional/XP/XP Professional x64 Edition).... 14

For Wired Network Interface Users
(For Windows® 98/98SE/Me/2000 Professional/XP/XP Professional x64 Edition).... 17

For Wireless Network Users (For Windows® 98/98SE/Me/2000 Professional/XP/
XP Professional x64 Edition in infrastructure mode)..... 21
For other setup methods supported, see the Network User's Guide on the CD-ROM for installation details.

Macintosh®

For USB Interface Users
(For Mac OS® X 10.2.4 or greater)..... 30

For Wired Network Interface Users
(For Mac OS® X 10.2.4 or greater)..... 33

For Wireless Network Users
(For Mac OS® X 10.2.4 or greater in infrastructure mode)..... 36
For other setup methods supported, see the Network User's Guide on the CD-ROM for installation details.

The screens for Windows® in this Quick Setup Guide are based on Windows® XP.
The screens for Mac OS® in this Quick Setup Guide are based on Mac OS ® X 10.4.

For USB Interface Users (For Windows® 98/98SE/Me/2000 Professional/XP/XP Professional x64 Edition)

Important

Make sure that you have finished the instructions from Step 1 *Setting Up the Machine* on page 4 through 11.

Note

- *Please close any applications running before installing MFL-Pro Suite.*
- *Make sure there are no memory cards in the media drive of the machine.*

1 Disconnect the machine from the power socket and from your computer, if you already connected an interface cable.



2 Turn on your PC.
(For Windows® 2000 Professional/XP/XP Professional x64 Edition, you must be logged on with Administrator rights.)

3 Put the supplied CD-ROM into your CD-ROM drive. If the model name screen appears, choose your machine. If the language screen appears, choose your language.

4 The CD-ROM main menu will appear. Click **Install MFL-Pro Suite**.



Note

- *If this window does not appear, use Windows® Explorer to run the **setup.exe** program from the root folder of the Brother CD-ROM.*
- ***If you are using Windows® 2000 Professional and have not installed service pack 3 (SP3) or greater:***
  To access the PhotoCapture Center™ features from your computer you may have to install a Windows® 2000 update first.
  The Windows® 2000 update is included with the MFL-Pro Suite installer.
  To install the update, follow the steps below:
  1 *Click **OK** to start installation of the Windows® updates.*



  2 *When instructed, click **OK** to restart your computer.*
  3 *After the computer restarts, the installation of MFL-Pro Suite will automatically continue.*

*If the installation does not continue automatically, open the main menu again by ejecting and then reinserting the CD-ROM disc or double-click the **setup.exe** program from the root folder, and continue from step **4** to install MFL-Pro Suite.*

5 Choose **Local Connection**, and then click **Next**. The installation continues.



6 After reading and accepting the ScanSoft® PaperPort® SE License Agreement, click **Yes**.



7 The installation of PaperPort® SE will automatically start and is followed by the installation of MFL-Pro Suite.

8 When the Brother MFL-Pro Suite Software License Agreement window appears, click **Yes** if you agree to the Software License Agreement.



9 When this screen appears, go to the next step.



10 Using both hands, use the plastic tabs on both sides of the machine to lift the scanner cover until it locks securely into the open position.



11 Connect the USB cable to the USB socket marked with a ⇐ symbol. You will find the USB socket inside the machine on the right as shown below.



12 Carefully guide the USB cable into the trench as shown below, following the trench around and toward the back of the machine. Then, connect the cable to your computer.



Improper Setup

- **DO NOT connect the machine to a USB port on a keyboard or a non-powered USB hub. Brother recommends that you connect the machine directly to your computer.**
- **Make sure that the cable does not restrict the cover from closing, or an error may occur.**

13 Lift the scanner cover to release the lock (①). Gently push the scanner cover support down (②) and close the scanner cover (③).



14 Turn on the machine by connecting the power cord.



The installation of the Brother drivers will automatically start. The installation screens appear one after another. **Please wait, it will take a few seconds for all the screens to appear.**

Improper Setup

DO NOT try to cancel any of the screens during this installation.

15 When the On-Line Registration screen is displayed, make your selection and follow the on-screen instructions.



16 Click **Finish** to restart your computer. (After restarting the computer, for Windows® 2000 Professional/XP/XP Professional x64 Edition, you must be logged on with Administrator rights.)



Note

After restarting the computer, the Installation Diagnostics will run automatically. If the installation is unsuccessful, the installation results window will be shown. If the Diagnostics shows a failure, please follow the on-screen instructions or read the on-line help and FAQs in ***Start/All Programs (Programs)/Brother/DCP-XXXX****.*

OK! **The MFL-Pro Suite has been installed and the installation is now complete.**

Note

- *MFL-Pro Suite includes the Printer Driver, Scanner Driver, Brother ControlCenter3, ScanSoft® PaperPort® SE with OCR and True Type® fonts.*
  PaperPort® SE is a document management application for scanning and viewing documents.
- *Windows® XP Professional x64 Edition does not support the Brother ControlCenter3 Modern user interface (see the Software User's Guide located on the CD-ROM for details).*

For Wired Network Interface Users (For Windows® 98/98SE/Me/2000 Professional/XP/XP Professional x64 Edition)

Important

Make sure that you have finished the instructions from Step 1 *Setting Up the Machine* on page 4 through 11.

1 Disconnect the machine from the power socket.

2 Using both hands, use the plastic tabs on both sides of the machine to lift the scanner cover until it locks securely into the open position.



3 Connect the network cable to the LAN socket marked with a symbol. You will find the LAN socket inside the machine on the left as shown below.



4 Carefully guide the network cable into the trench as shown below, following the trench around and toward the back of the machine. Then, connect the cable to your network.



Improper Setup

Make sure that the cable does not restrict the cover from closing, or an error may occur.

Note

If both USB and LAN cables are being used, guide both cables through the trench with one on top of the other.

5 Lift the scanner cover to release the lock (①). Gently push the scanner cover support down (②) and close the scanner cover (③).



6 Turn on the machine by connecting the power cord.



Improper Setup

If you have setup wireless networking on your machine before and you setup the wired network, you should check that the machine's `Network I/F` is `Wired LAN`. The wireless network interface will be inactive with this setting.
On your machine, press Menu.
Press ▲ or ▼ to choose `LAN` and press OK.
Press ▲ or ▼ to choose `Network I/F` and press OK.
Press ▲ or ▼ to choose `Wired LAN` and press OK.

7 Turn on your computer.
(For Windows® 2000 Professional/XP/ XP Professional x64 Edition, you must be logged on with Administrator rights.)
Close any applications running before installing the MFL-Pro Suite.

Note

Before installation, if you are using Personal Firewall software, disable it.

8 Put the supplied CD-ROM into your CD-ROM drive. If the model name screen appears, choose your machine. If the language screen appears, choose your language.

9 The CD-ROM main menu will appear. Click **Install MFL-Pro Suite**.



Note

- *If this window does not appear, use Windows® Explorer to run the **setup.exe** program from the root folder of the Brother CD-ROM.*
- *If you see the following screen, click **OK** to install the Windows® updates. After the updates are installed your PC may restart. Then the installation will automatically continue.*



*If the installation does not continue automatically, open the main menu again by ejecting then reinserting the CD-ROM disc or double-click the **setup.exe** program from the root folder, and continue from step **9** to install MFL-Pro Suite.*

10 Choose **Wired Network Connection**, and then click **Next**.



11 After reading and accepting the ScanSoft® PaperPort® SE License Agreement, click **Yes**.



12 The installation of PaperPort® SE will automatically start and is followed by the installation of MFL-Pro Suite.

13 When the Brother MFL-Pro Suite Software License Agreement window appears, click **Yes** if you agree to the Software License Agreement.



14 The installation of the Brother drivers will automatically start. The installation screens appear one after another. **Please wait, it will take a few seconds for all the screens to appear.**

Improper Setup

DO NOT try to cancel any of the screens during this installation.

15 If the machine is configured for your network, choose the machine from the list, and then click **Next**.



Note

This window will not appear if there is only one machine connected on the network, it will be chosen automatically.

16 If the machine is not yet configured for use on your network, the following screen appears.



Click **OK**.
The **Configure IP Address** window will appear. Enter an IP address for your machine that is suitable for your network by following the on-screen instructions.

17 When the Brother and ScanSoft On-Line Registration screen is displayed, make your selection and follow the on-screen instructions.



18 Click **Finish** to restart your computer. (For Windows® 2000 Professional/XP/ XP Professional x64 Edition, you must be logged on with Administrator rights.)



Note

- *After restarting the computer, the Installation Diagnostics will run automatically. If the installation is unsuccessful, the installation results window will be shown. If the Diagnostics shows a failure, please follow the on-screen instructions or read the on-line help and FAQs in **Start/All Programs (Programs)/Brother/ DCP-XXXX**.*
- *Once you are sure that you can print after the installation, restart your Firewall software.*
- *Firewall settings on your PC may reject the necessary network connection for Network Scanning.*
  Follow the instructions below to configure your Windows Firewall. If you are using a personal Firewall software, see the User's Guide for your software or contact the software manufacturer.
- ***For Windows® XP SP2 users:***
  1 *Click the **Start** button, **Control Panel** and then **Windows Firewall**.*
  *Make sure that Windows Firewall on the **General** tab is set to On.*

2 Click the **Advanced** tab and **Settings...** button.



3 Click the **Add** button.

4 Add port 54925 for network scanning, enter the information below:
1) (Any description)
2) Localhost
3) 54925
4) 54925
5) Select **UDP**
Then, click **OK**.



5 If you still have trouble with your network connection, click the **Add** button.

6 Add port 137 for network scanning, enter the information below:
1) (Any description)
2) Localhost
3) 137
4) 137
5) Select **UDP**
Then, click **OK**.

7 Make sure if the new settings are added and are checked, and then click **OK**.

The MFL-Pro Suite has been installed and the installation is now complete.

Note

- *MFL-Pro Suite includes the Network Printer Driver, Network Scanner Driver, Brother ControlCenter3, ScanSoft® PaperPort® SE with OCR and True Type® fonts.*
  PaperPort® SE is a document management application for scanning and viewing documents.
- *Windows® XP Professional x64 Edition does not support the Brother ControlCenter3 Modern user interface (see the Software User's Guide located on the CD-ROM for details).*

For Wireless Network Users (For Windows® 98/98SE/Me/2000 Professional/XP/XP Professional x64 Edition in infrastructure mode)

Connect your wireless machine and wireless network together: install the printer driver in infrastructure mode

First you must configure the wireless network settings of your machine to communicate with your network access point (router). After the machine is configured to communicate with your access point (router) computers on your network will have access to the machine. To use the machine from these computers, you will need to install the MFL-Pro Suite. The following steps will guide you through the configuration and installation process.

To achieve optimum results with normal every day document printing, place the Brother machine as close to the network access point (router) as possible with minimal obstructions. Large objects and walls between the two devices as well as interference from other electronic devices can affect the data transfer speed of your documents.

Important

The following instructions will offer two methods for installing your Brother machine in a wireless network environment. Both methods are for infrastructure mode, using a wireless router or access point that uses DHCP to assign IP addresses. If your wireless router/access point supports SecureEasySetup™ follow the steps on page 23 *Using the SecureEasySetup™ software to configure your machine for a wireless network*. If your wireless router/access point does not support SecureEasySetup™ follow the steps on page 25 *Using the Setup Wizard from the control panel LAN menu for wireless network configuration*. To set up your machine in any other wireless environment you can find instructions in the Network User's Guide on the CD-ROM.

You can view the Network User's Guide by following the instructions below.

1 Turn on your PC. Insert the Brother CD-ROM into your CD-ROM drive.
2 If the model name screen appears, click your model name.
3 If the language screen appears, click your language. The CD-ROM main menu will appear.
4 Click the **User's Guide**.
5 Click the **Network User's Guide**.

Confirm your network environment

The setup process will be different depending on your network environment.

■ **Installation using SecureEasySetup™.**



If your wireless access point (A) supports SecureEasySetup™, you do not need to use a computer to configure the machine. The access point (router) and your machine can automatically negotiate using the SecureEasySetup™ procedure.
For instructions, go to page 23.

■ **Infrastructure Mode**



If your wireless access point (A) does not support SecureEasySetup™, follow the instructions, on page 25.

Using the SecureEasySetup™ software to configure your machine for a wireless network

Important

Make sure that you have finished the instructions from Step 1 *Setting Up the Machine* on page 4 through 11.

The SecureEasySetup™ software allows you to configure the wireless network easier than configuring it manually. By pushing a button on the wireless router or access point, you can complete setup and secure the wireless network. Your router or access point must also support SecureEasySetup™. See the user's guide for your wireless LAN router or access point for instructions to configure your machine for a wireless network. If your wireless router or access point does not support SecureEasySetup™ go to page 25 for installation instructions.



Note

Routers or access points that support SecureEasySetup™ have the SecureEasySetup™ symbol as shown below.

1 Turn on the machine by connecting the power cord.



Improper Setup

If you have previously configured the wireless settings of the machine you must reset the network (LAN) settings before you can configure the wireless settings again.
On your machine, press Menu. Press ▲ or ▼ to choose `LAN` and then press OK.
Press ▲ or ▼ to choose `Factory Reset`, and then press OK.
Press + to choose `Yes`.
Press + to choose `Yes`.

2 Place the Brother machine close to the SecureEasySetup™ router or access point (less than 5 m/16 feet).

3 Push the SecureEasySetup™ button on your wireless router or access point. See the user's guide for your wireless router or access point for instructions.

4 On your machine, press **Menu**.
Press ▲ or ▼ to choose `LAN` and press **OK**.
Press ▲ or ▼ to choose `Network I/F` and press **OK**.
Press ▲ or ▼ to choose `WLAN` and press **OK**.
The wired network interface will become inactive with this setting.
It will take about a minute for the LAN menu on the LCD to become available again.
Press **Stop/Exit**.

5 When the LAN menu becomes available, press **Menu**.
Press ▲ or ▼ to choose `LAN` and press **OK**.
Press ▲ or ▼ to choose `Setup WLAN` and press **OK**.
Press ▲ or ▼ to choose `SecureEasySetup` and press **OK**.

6 The wireless network connection status using the SecureEasySetup™ software will be displayed: `Connecting WLAN`, `Connected` or `Connection Error`.

`Connecting WLAN` is displayed when the print server is trying to make connections to your router or access point. Wait till either `Connected` or `Connection Error` is displayed.

`Connected` is displayed when the print server is successfully connected to your router or access point. You can now use your machine in a wireless network.

`Connection Error` is displayed when the print server has not successfully connected to your router or access point. Try starting from step **2** again. If the same message is displayed again, reset the print server back to the default factory settings and try again.
(See *Restoring the network settings to factory default* on page 45.)

OK!

Wireless setup is now complete. To install the MFL-Pro suite, continue to step 13 on page 27.

Using the Setup Wizard from the control panel LAN menu for wireless network configuration

Important

Make sure that you have finished the instructions from Step 1 *Setting Up the Machine* on page 4 through 11.

1 Write down the wireless network settings of your access point or wireless router.

SSID (Service Set ID or Network name)

_____

WEP Key (if needed)

_____

WPA/WPA2-PSK (TKIP or AES) (if needed)

_____

The WEP key is for 64 bit encrypted networks or 128 bit encrypted networks and can contain both numbers and letters. If you do not know this information you should see the documentation provided with your access point or wireless router. This key is a 64-bit or 128-bit value that must be entered in an ASCII or HEXADECIMAL format.

For example:

64 bit ASCII:	*Uses 5 text characters.* *e.g. "Hello" (this is case sensitive)*
64 bit Hexadecimal:	*Uses 10 digits of hexadecimal data.* *e.g. "71f2234aba"*
128 bit ASCII:	*Uses 13 text characters.* *e.g. "Wirelesscomms" (this is case sensitive)*
128 bit Hexadecimal:	*Uses 26 digits of hexadecimal data.* *e.g. "71f2234ab56cd709e5412aa3ba"*

WPA/WPA2-PSK enables a Wi-Fi® Protected Access Pre-shared key (WPA/WPA2-PSK), which lets the Brother wireless machine associate with access points using TKIP or AES encryption (WPA-Personal). WPA/WPA2-PSK (TKIP or AES) uses a Pre-Shared Key (PSK) that is more than 7 and less than 64 characters in length.
See the Network User's Guide for more details.

2 Turn on the machine by connecting the power cord.



Improper Setup

If you have previously configured the wireless settings of the machine you must reset the network (LAN) settings before you can configure the wireless settings again.
On your machine, press Menu.
Press ▲ or ▼ for `LAN` and press OK.
Press ▲ or ▼ to choose `Factory Reset`, and then press OK.
Press + to choose `Yes`.
Press + to choose `Yes`.

3 On your machine, press **Menu**.
Press ▲ or ▼ to choose `LAN` and press **OK**.
Press ▲ or ▼ to choose `Network I/F` and press **OK**.
Press ▲ or ▼ to choose `WLAN` and press **OK**.
The wired network interface will become inactive with this setting.
It will take about a minute for the LAN menu on the LCD to become available again.
Press **Stop/Exit**.

4 When the LAN menu becomes available, press **Menu**.
Press ▲ or ▼ to choose `LAN` and press **OK**.
Press ▲ or ▼ to choose `Setup WLAN` and press **OK**.
Press ▲ or ▼ to choose `Setup Wizard` and press **OK**.
This will start the wireless setup wizard.

5 The machine will search for available SSIDs. If a list of SSIDs is displayed, use the ▲ or ▼ keys to choose the SSID you wrote down in step **1**, then press **OK**. Go to step **9**.

Note

It will take a few seconds to display a list of available SSIDs.

If your access point is set to not broadcast the SSID you will have to manually add the SSID name. Go to step **6**.

6 Select <NEW SSID> using ▲ or ▼ and press **OK**. Go to step **7**.

7 Enter the SSID you wrote down in step **1** using ▲, ▼ and **OK** keys to choose each letter or number. You can use the ◄ and ► keys to move the cursor left and right. For example, to enter the letter a, press the ▲ key once. To enter the number 3, hold down the ▲ key until it appears.
The letters appear in this order: lower case, upper case, numbers and then special letters. (For more information, see *Entering Text* on page 46.)

Press **OK** when you have entered all the characters, then press + Yes to apply your settings.

8 Press ▲ or ▼ to choose Infrastructure, then press **OK**.

9 Use the ▲, ▼ and **OK** keys to choose one of the options below: If your network is configured for Authentication and Encryption you must match the settings used for your network.

No Authentication or Encryption: Choose Open System, press **OK** then choose None for Encryption Type and press **OK**. Then press + to choose Yes to apply your settings. Go to step **12**.

No Authentication with WEP Encryption: Choose Open System, press **OK** then use the ▲ or ▼ to choose WEP for the Encryption Type and press **OK**. Go to step **10**.

Authentication with WEP Encryption: Choose Shared Key, press **OK**. Go to step **10**.

Authentication with WPA/WPA2-PSK (TKIP or AES) Encryption: Choose WPA/WPA2-PSK, press **OK**. Go to step **11**.

10 Choose the appropriate key number and press **OK**. Enter the WEP key you wrote down in step **1** using ▲, ▼ and **OK** keys to choose each letter or number. You can use the ◄ and ► keys to move the cursor left and right. For example, to enter the letter a, press the ▲ key once. To enter the number 3, hold down the ▲ key until it appears.
The letters appear in this order: lower case, upper case, numbers and then special letters. (For more information, see *Entering Text* on page 46.)

Press **OK** when you have entered all the characters, then press + Yes to apply your settings. Go to step **12**.

Most access points and routers can store more than one key, but they will only use one at any time for authentication and encryption.

11 Press ▲ or ▼ to choose TKIP or AES for Encryption Type and press **OK**.
Enter the WPA/WPA2-PSK password you wrote down in step **1** using ▲, ▼ and **OK** keys to choose each letter or number. You can use the ◄ and ► keys to move the cursor left and right. For example, to enter the letter a, press the ▲ key once. To enter the number 3, hold down the ▲ key until it appears.

The letters appear in this order: lower case, upper case, numbers and then special letters. (For more information, see *Entering Text* on page 46.)

Press **OK** when you have entered all the characters, then press + Yes to apply your settings. Go to step **12**.

12 Your machine will now try to connect to your wireless network using the information you have entered. If successful, Connected will appear briefly on the LCD.

If your machine does not successfully connect to your network, you should repeat steps **4** *to* **11** *to make sure you have entered the correct information.*

If your access point does not have DHCP enabled you will need to manually configure the IP address, subnet mask and gateway of the machine to suit your network. See the Network User's Guide for details.

Wireless setup is now complete. A four level indicator on the bottom of your machine's LCD will show the wireless signal strength of your access point or router. To install the MFL-Pro Software suite, continue to step 13.

13 Turn on your computer.
(For Windows® 2000 Professional/XP/ XP Professional x64 Edition, you must be logged on with Administrator rights.)
Close any applications running before installing the MFL-Pro Suite.

Note

Before installation, if you are using personal firewall software, disable it.

14 Put the supplied CD-ROM into your CD-ROM drive. If the model name screen appears, choose your machine. If the language screen appears, choose your language.

15 The CD-ROM main menu will appear. Click **Install MFL-Pro Suite**.



Note

- *If this window does not appear, use Windows® Explorer to run the **setup.exe** program from the root folder of the Brother CD-ROM.*
- *If you see the following screen, click **OK** to install the Windows® updates. After the updates are installed your PC may restart. Then the installation will automatically continue.*



*If the installation does not continue automatically, open the main menu again by ejecting then reinserting the CD-ROM disc or double-click the **setup.exe** program from the root folder, and continue from step **15** to install MFL-Pro Suite.*

16 Choose **Wireless Network Connection**, and then click **Next**.



17 Click on **Checked and confirmed** check box, and then click **Next**.



18 After reading and accepting the ScanSoft® PaperPort® SE License Agreement, click **Yes**.



19 The installation of PaperPort® SE will automatically start and is followed by the installation of MFL-Pro Suite.

20 When the Brother MFL-Pro Suite Software License Agreement window appears, click **Yes** if you agree to the Software License Agreement.



Windows® Wireless Network

21 The installation of the Brother drivers will automatically start. The installation screens appear one after another. **Please wait, it will take a few seconds for all the screens to appear**.

Improper Setup

- **DO NOT try to cancel any of the screens during this installation.**
- **If your wireless settings fail, an error message will appear during the installation of MFL-Pro Suite and the installation will be terminated. If you encounter this failure, please go to step 1 and setup the wireless connection again.**

22 Choose the machine from the list, and then click **Next**.



Note

This window will not appear if there is only one of this Brother model connected on the network as it will be chosen automatically.

23 When the Brother and ScanSoft On-Line Registration screen is displayed, make your selection and follow the on-screen instructions.



24 Click **Finish** to restart your computer. (For Windows® 2000 Professional/XP/ XP Professional x64 Edition, you must be logged on with Administrator rights.)



Note

- *After restarting the computer, the Installation Diagnostics will run automatically. If the installation is unsuccessful, the installation results window will be shown. If the Diagnostics shows a failure, please follow the on-screen instructions or read the on-line help and FAQs in **Start/All Programs (Programs)/Brother/ DCP-XXXX**.*
- *Once you are sure that you can print after the installation, restart your Firewall software.*
- *Firewall settings on your PC may reject the necessary network connection for Network Scanning.*
  Follow the instructions below to configure your Windows Firewall. If you are using a personal Firewall software, see the User's Guide for your software or contact the software manufacturer.
- ***For Windows® XP SP2 users:***
  1 *Click the **Start** button, **Control Panel** and then **Windows Firewall**.*
  *Make sure that Windows Firewall on the **General** tab is set to On.*
  2 *Click the **Advanced** tab and **Settings...** button.*



  3 *Click the **Add** button.*
  4 *Add port 54925 for network scanning, enter the information below:*
  1) (Any description)
  2) Localhost
  3) 54925
  4) 54925
  *5) Select **UDP***
  *Then, click **OK**.*



  5 *If you still have trouble with your network connection, click the **Add** button.*

6 *Add port 137 for network scanning, enter the information below:*
1) (Any description)
2) Localhost
3) 137
4) 137
*5) Select **UDP***
*Then, click **OK**.*

7 *Make sure if the new settings are added and are checked, and then click **OK**.*

The MFL-Pro Suite has been installed and the installation is now complete.

Note

- *MFL-Pro Suite includes the Network Printer Driver, Network Scanner Driver, Brother ControlCenter3, ScanSoft® PaperPort® SE with OCR and True Type® fonts.*
  PaperPort® SE is a document management application for scanning and viewing documents.
- *Windows® XP Professional x64 Edition does not support the Brother ControlCenter3 Modern user interface (see the Software User's Guide located on the CD-ROM for details).*

For USB Interface Users (For Mac OS® X 10.2.4 or greater)

Important

Make sure that you have finished the instructions from Step 1 *Setting Up the Machine* on page 4 through 11.

Note

For Mac OS® X 10.2.0 to 10.2.3 users, upgrade to Mac OS® X 10.2.4 or greater. (For the latest information for Mac OS® X, visit http://solutions.brother.com)

1 Using both hands, use the plastic tabs on both sides of the machine to lift the scanner cover until it locks securely into the open position.



2 Connect the USB cable to the USB socket marked with a symbol. You will find the USB socket inside the machine on the right as shown below.



3 Carefully guide the USB cable into the trench as shown below, following the trench around and toward the back of the machine. Then, connect the cable to your computer.



Improper Setup

- **DO NOT connect the machine to a USB port on a keyboard or a non-powered USB hub. Brother recommends that you connect the machine directly to your computer.**
- **Make sure that the cable does not restrict the cover from closing, or an error may occur.**

4 Lift the scanner cover to release the lock (①). Gently push the scanner cover support down (②) and close the scanner cover (③).



Note

Make sure that the machine is turned on by connecting the power cord.

5 Turn on your Macintosh®.

6 Put the supplied CD-ROM into your CD-ROM drive.

7 Double-click the **Start Here OSX** icon to install.



8 Choose **Local Connection**, and then click **Next**. Follow the on-screen instruction.

Note

Please wait, it will take a few seconds for the software to install. After the installation, click ***Restart*** *to finish installing the software.*

9 The Brother software will search for the Brother device. During this time the following screen will appear.



10 When this screen appears, click **OK**.

OK! **For Mac OS® X 10.3.x or greater users: The MFL-Pro Suite, Brother printer driver, scanner driver and Brother ControlCenter2 have been installed and the installation is now complete. Go to step 15.**

11 For Mac OS® X 10.2.4 to 10.2.8 users: Click **Add**.



12 Choose **USB**.



13 Choose **DCP-XXXX** (where XXXX is your model name), and then click **Add**.



14 Click **Print Center**, then **Quit Print Center**.





OK! **The MFL-Pro Suite, Brother printer driver, scanner driver and Brother ControlCenter2 have been installed and the installation is now complete.**

15 To install Presto!® PageManager®, click the **Presto! PageManager** icon and follow the on-screen instructions.



Note

When Presto!® PageManager® is installed OCR capability is added to the Brother ControlCenter2. You can easily scan, share and organize photos and documents using Presto!® PageManager®.

OK!

Presto!® PageManager® has been installed and the installation is now complete.

For Wired Network Interface Users (For Mac OS® X 10.2.4 or greater)

Important

Make sure that you have finished the instructions from Step 1 *Setting Up the Machine* on page 4 through 11.

1 Using both hands, use the plastic tabs on both sides of the machine to lift the scanner cover until it locks securely into the open position.



2 Connect the network cable to the LAN socket marked with a symbol. You will find the LAN socket inside the machine on the left as shown below.



3 Carefully guide the network cable to the trench as shown below, following the trench around and toward the back of the machine.
Then, connect the cable to your network.



Improper Setup

Make sure that the cable does not restrict the cover from closing, or an error may occur.

Note

If both USB and LAN cables are being used, guide both cables through the trench with one on top of the other.

4 Lift the scanner cover to release the lock (①). Gently push the scanner cover support down (②) and close the scanner cover (③).



Note

Make sure that the machine is turned on by connecting the power cord.

Improper Setup

If you have setup wireless networking on your machine before and you setup the wired network, you should check that the machine's `Network I/F` is `Wired LAN`. The wireless network interface will be inactive with this setting.
On your machine, press Menu.
Press ▲ or ▼ to choose `LAN` and press OK.
Press ▲ or ▼ to choose `Network I/F` and press OK.
Press ▲ or ▼ to choose `Wired LAN` and press OK.

5 Turn on your Macintosh®.

6 Put the supplied CD-ROM into your CD-ROM drive.

7 Double-click the **Start Here OSX** icon to install.

8 Choose **Wired Network Connection**, and then click **Next**. Follow the on-screen instructions.



Please wait, it will take a few seconds for the software to install. After the installation, click **Restart** to finish installing the software.

9 The Brother software will search for the Brother device. During this time the following screen will appear.



Note

- *If the machine is configured for your network, choose the machine from the list, and then click **OK**.*
  *This window will not appear if there is only one machine connected on the network, it will be chosen automatically. Go to step **10**.*



- *If this screen appears click **OK**.*



- *Enter a name for your Macintosh® in **Display Name** up to 15 characters long and click **OK**. Go to step **10**.*



- *If you want to use the machine's Scan key to scan over the network you must check the **Register your computer with the "Scan To" function on the machine** box.*
- *The name you enter will appear on the machine's LCD when you press the **Scan** key and choose a scan option. (For more information, see Network Scanning in the Software User's Guide on the CD-ROM.)*

10 Click **Add**.



Note

*For Mac OS® X 10.4 users, go to step **13**.*

11 For Mac OS® X 10.2.4 to 10.3.x users: Make the selection shown below.



Macintosh® Wired Network

12 Choose **DCP-XXXX** (where XXXX is your model name), and then click **Add**.
Go to step **14**.



13 For Mac OS® X 10.4 users:
Choose **DCP-XXXX** (where XXXX is your model name), and then click **Add**.



14 Click **Printer Setup Utility**, then **Quit Printer Setup Utility**.



Note

*For Mac OS® X 10.2.x users, click **Print Center**, then **Quit Print Center**.*

OK! **The MFL-Pro Suite, Brother printer driver, scanner driver and Brother ControlCenter2 have been installed and the installation is now complete.**

15 To install Presto!® PageManager®, click the **Presto! PageManager** icon and follow the on-screen instructions.



Note

When Presto!® PageManager® is installed OCR capability is added to the Brother ControlCenter2. You can easily scan, share and organize photos and documents using Presto!® PageManager®.

OK! **Presto!® PageManager® has been installed and the installation is now complete.**

For Wireless Network Users (For Mac OS® X 10.2.4 or greater in infrastructure mode)

Connect your wireless machine and wireless network together: install the printer driver in infrastructure mode

First you must configure the wireless network settings of your machine to communicate with your network access point (router). After the machine is configured to communicate with your access point (router) computers on your network will have access to the machine. To use the machine from these computers, you will need to install the MFL-Pro Suite. The following steps will guide you through the configuration and installation process.

To achieve optimum results with normal every day document printing, place the Brother machine as close to the network access point (router) as possible with minimal obstructions. Large objects and walls between the two devices as well as interference from other electronic devices can affect the data transfer speed of your documents.

Important

The following instructions will offer two methods for installing your Brother machine in a wireless network environment. Both methods are for infrastructure mode, using a wireless router or access point that uses DHCP to assign IP addresses. If your wireless router/access point supports SecureEasySetup™ follow the steps on page 38 *Using the SecureEasySetup™ software to configure your machine for a wireless network*. If your wireless router/access point does not support SecureEasySetup™ follow the steps on page 39 *Using the Setup Wizard from the control panel LAN menu for wireless network configuration*. To set up your machine in any other wireless environment you can find instructions in the Network User's Guide on the CD-ROM.

You can view the Network User's Guide by following the instructions below.

1 Turn on your Macintosh®. Insert the Brother CD-ROM into your CD-ROM drive.
2 Double-click **Documentation**.
3 Double-click your language folder.
4 Double-click the Network User's Guide.

Confirm your network environment

The setup process will be different depending on your network environment.

■ **Installation using SecureEasySetup™.**



If your wireless access point (A) supports SecureEasySetup™, you do not need to use a computer to configure the machine. The access point (router) and your machine can automatically negotiate using the SecureEasySetup™ procedure.

For instructions, go to page 38.

■ **Infrastructure Mode**



If your wireless access point (A) does not support SecureEasySetup™, follow the instructions, on page 39.

Using the SecureEasySetup™ software to configure your machine for a wireless network

Important

Make sure that you have finished the instructions from Step 1 *Setting Up the Machine* on page 4 through 11.

The SecureEasySetup™ software allows you to configure the wireless network easier than configuring it manually. By pushing a button on the wireless router or access point, you can complete setup and secure the wireless network. Your router or access point must also support SecureEasySetup™. See the user's guide for your wireless LAN router or access point for instructions to configure your machine for a wireless network. If your wireless router or access point does not support SecureEasySetup™ go to page 39 for installation instructions.



Note

Routers or access points that support SecureEasySetup™ have the SecureEasySetup™ symbol as shown below.

Note

Make sure that the machine is turned on by connecting the power cord.

Improper Setup

If you have previously configured the wireless settings of the machine you must reset the network (LAN) settings before you can configure the wireless settings again.
On your machine, press Menu. Press ▲ or ▼ to choose `LAN` and then press OK.
Press ▲ or ▼ to choose `Factory Reset`, and then press OK.
Press + to choose `Yes`.
Press + to choose `Yes`.

1 Place the Brother machine close to the SecureEasySetup™ router or access point (less than 5 m/16 feet).

2 Push the SecureEasySetup™ button on your wireless router or access point. See the user's guide for your wireless router or access point for instructions.

3 On your machine, press **Menu**.
Press ▲ or ▼ to choose `LAN` and press **OK**.
Press ▲ or ▼ to choose `Network I/F` and press **OK**.
Press ▲ or ▼ to choose `WLAN` and press **OK**.
The wired network interface will become inactive with this setting.
It will take about a minute for the LAN menu on the LCD to become available again.
Press **Stop/Exit**.

4 When the LAN menu becomes available, press **Menu**.
Press ▲ or ▼ to choose `LAN` and press **OK**.
Press ▲ or ▼ to choose `Setup WLAN` and press **OK**.
Press ▲ or ▼ to choose `SecureEasySetup` and press **OK**.

5 The wireless network connection status using the SecureEasySetup™ software will be displayed: `Connecting WLAN`, `Connected` or `Connection Error`.

`Connecting WLAN` is displayed when the print server is trying to make connections to your router or access point. Wait till either `Connected` or `Connection Error` is displayed.

`Connected` is displayed when the print server is successfully connected to your router or access point. You can now use your machine in a wireless network.

`Connection Error` is displayed when the print server has not successfully connected to your router or access point. Try starting from step **1** again. If the same message is displayed again, reset the print server back to the default factory settings and try again.
(See *Restoring the network settings to factory default* on page 45.)

OK! **Wireless setup is now complete. To install the MFL-Pro suite, continue to step 12 on page 40.**

Using the Setup Wizard from the control panel LAN menu for wireless network configuration

Important

Make sure that you have finished the instructions from Step 1 *Setting Up the Machine* on page 4 through 11.

1 Write down the wireless network settings of your access point or wireless router.

SSID (Service Set ID or Network name)

_____

WEP Key (if needed)

_____

WPA/WPA2-PSK (TKIP or AES) (if needed)

_____

The WEP key is for 64 bit encrypted networks or 128 bit encrypted networks and can contain both numbers and letters. If you do not know this information you should see the documentation provided with your access point or wireless router. This key is a 64-bit or 128-bit value that must be entered in an ASCII or HEXADECIMAL format.

For example:

64 bit ASCII:	*Uses 5 text characters.* *e.g. "Hello" (this is case sensitive)*
64 bit Hexadecimal:	*Uses 10 digits of hexadecimal data.* *e.g. "71f2234aba"*
128 bit ASCII:	*Uses 13 text characters.* *e.g. "Wirelesscomms" (this is case sensitive)*
128 bit Hexadecimal:	*Uses 26 digits of hexadecimal data.* *e.g. "71f2234ab56cd709e5412aa3ba"*

WPA/WPA2-PSK enables a Wi-Fi® Protected Access Pre-shared key (WPA/WPA2-PSK), which lets the Brother wireless machine associate with access points using TKIP or AES encryption (WPA-Personal). WPA/WPA2-PSK (TKIP or AES) uses a Pre-Shared Key (PSK) that is more than 7 and less than 64 characters in length.
See the Network User's Guide for more details.

Note

Make sure that the machine is turned on by connecting the power cord.

Improper Setup

If you have previously configured the wireless settings of the machine you must reset the network (LAN) settings before you can configure the wireless settings again.
On your machine, press Menu.
Press ▲ or ▼ for `LAN` and press OK.
Press ▲ or ▼ to choose `Factory Reset`, and then press OK.
Press + to choose `Yes`.
Press + to choose `Yes`.

2 On your machine, press **Menu**.
Press ▲ or ▼ to choose `LAN` and press **OK**.
Press ▲ or ▼ to choose `Network I/F` and press **OK**.
Press ▲ or ▼ to choose `WLAN` and press **OK**.
The wired network interface will become inactive with this setting.
It will take about a minute for the LAN menu on the LCD to become available again.
Press **Stop/Exit**.

3 When the LAN menu becomes available, press **Menu**.
Press ▲ or ▼ to choose `LAN` and press **OK**.
Press ▲ or ▼ to choose `Setup WLAN` and press **OK**.
Press ▲ or ▼ to choose `Setup Wizard` and press **OK**.
This will start the wireless setup wizard.

4 The machine will search for available SSIDs. If a list of SSIDs is displayed, use the ▲ or ▼ keys to choose the SSID you wrote down in step **1**, then press **OK**. Go to step **8**.

Note

It will take a few seconds to display a list of available SSIDs.

If your access point is set to not broadcast the SSID you will have to manually add the SSID name. Go to step **5**.

5 Select `<NEW SSID>` using ▲ or ▼ and press **OK**. Go to step **6**.

6 Enter the SSID you wrote down in step **1** using ▲, ▼ and **OK** keys to choose each letter or number. You can use the ◄ and ► keys to move the cursor left and right. For example, to enter the letter a, press the ▲ key once. To enter the number 3, hold down the ▲ key until it appears.
The letters appear in this order: lower case, upper case, numbers and then special letters. (For more information, see *Entering Text* on page 46.)

Press **OK** when you have entered all the characters, then press + Yes to apply your settings.

7 Press ▲ or ▼ to choose Infrastructure, then press **OK**.

8 Use the ▲, ▼ and **OK** keys to choose one of the options below: If your network is configured for Authentication and Encryption you must match the settings used for your network.

No Authentication or Encryption: Choose Open System, press **OK** then choose None for Encryption Type and press **OK**. Then press + to choose Yes to apply your settings. Go to step **11**.

No Authentication with WEP Encryption: Choose Open System, press **OK** then use the ▲ or ▼ to choose WEP for the Encryption Type and press **OK**. Go to step **9**.

Authentication with WEP Encryption: Choose Shared Key, press **OK**. Go to step **9**.

Authentication with WPA/WPA2-PSK (TKIP or AES) Encryption: Choose WPA/WPA2-PSK, press **OK**. Go to step **10**.

9 Choose the appropriate key number and press **OK**. Enter the WEP key you wrote down in step **1** using ▲, ▼ and **OK** keys to choose each letter or number. You can use the ◄ and ► keys to move the cursor left and right. For example, to enter the letter a, press the ▲ key once. To enter the number 3, hold down the ▲ key until it appears.
The letters appear in this order: lower case, upper case, numbers and then special letters. (For more information, see *Entering Text* on page 46.)

Press **OK** when you have entered all the characters, then press + Yes to apply your settings. Go to step **11**.

Most access points and routers can store more than one key, but they will only use one at any time for authentication and encryption.

10 Press ▲ or ▼ to choose TKIP or AES for Encryption Type and press **OK**.
Enter the WPA/WPA2-PSK password you wrote down in step **1** using ▲, ▼ and **OK** keys to choose each letter or number. You can use the ◄ and ► keys to move the cursor left and right. For example, to enter the letter a, press the ▲ key once. To enter the number 3, hold down the ▲ key until it appears.

The letters appear in this order: lower case, upper case, numbers and then special letters. (For more information, see *Entering Text* on page 46.)

Press **OK** when you have entered all the characters, then press + Yes to apply your settings. Go to step **11**.

11 Your machine will now try to connect to your wireless network using the information you have entered. If successful, Connected will appear briefly on the LCD.

If your machine does not successfully connect to your network, you should repeat steps **3** *to* **10** *to make sure you have entered the correct information.*

If your access point does not have DHCP enabled you will need to manually configure the IP address, subnet mask and gateway of the machine to suit your network. See the Network User's Guide for details.

OK! **Wireless setup is now complete. A four level indicator on the bottom of your machine's LCD will show the wireless signal strength of your access point or router. To install the MFL-Pro Software suite, continue to step 12.**

12 Turn on your Macintosh®.

13 Put the supplied CD-ROM into your CD-ROM drive.



14 Double-click the **Start Here OSX** icon to install.

15 Choose **Wireless Network Connection**, and then click **Next**.

16 Click on the **Checked and confirmed** check box, and then click **Next**.
Follow the on-screen instructions.

Please wait, it will take a few seconds for the software to install. After the installation, click **Restart** to finish installing the software.

17 The Brother software will search for the Brother device. During this time the following screen will appear.



Note

- *If the machine is configured for your network, choose the machine from the list, and then click **OK**.*
  *This window will not appear if there is only one machine connected on the network, it will be chosen automatically. Go to step **18**.*



- *If this screen appears click **OK**.*

- *Enter a name for your Macintosh® in **Display Name** up to 15 characters long and click **OK**. Go to step **18**.*



- *If you want to use the machine's Scan key to scan over the network you must check the **Register your computer with the "Scan To" function on the machine** box.*
- *The name you enter will appear on the machine's LCD when you press the **Scan** key and choose a scan option. (For more information, see Network Scanning in the Software User's Guide on the CD-ROM.)*

18 Click **Add**.



Note

*For Mac OS® X 10.4 users, go to step **21**.*

19 For Mac OS® X 10.2.4 to 10.3.x users:
Make the selection shown below.



20 Choose **DCP-XXXX** (where XXXX is your model name), and then click **Add**.
Go to step **22**.



21 For Mac OS® X 10.4 users:
Choose **DCP-XXXX** (where XXXX is your model name), and then click **Add**.



22 Click **Printer Setup Utility**, then **Quit Printer Setup Utility**.





Note

*For Mac OS® X 10.2.x users, click **Print Center**, then **Quit Print Center**.*

OK! **The MFL-Pro Suite, Brother printer driver, scanner driver and Brother ControlCenter2 have been installed and the installation is now complete.**

23 To install Presto!® PageManager®, click the **Presto! PageManager** icon and follow the on-screen instructions.



Note

When Presto!® PageManager® is installed OCR capability is added to the Brother ControlCenter2. You can easily scan, share and organize photos and documents using Presto!® PageManager®.

OK! **Presto!® PageManager® has been installed and the installation is now complete.**

BRAdmin Professional configuration utility (For Windows® users)

The BRAdmin Professional utility for Windows® is designed to manage your Brother network connected devices such as network-ready Multifunction devices and /or network-ready printers in a Local Area Network (LAN) environment. For more information on BRAdmin Professional, visit us at http://solutions.brother.com.

Installing the BRAdmin Professional configuration utility

1 Put the supplied CD-ROM into your CD-ROM drive. The opening screen will appear automatically. Follow the on-screen instructions.

2 Click **Install Optional Applications** on the menu screen.



3 Click **BRAdmin Professional** and follow the on-screen instructions.



Setting your IP address, Subnet Mask and Gateway using BRAdmin Professional

1 Start BRAdmin Professional, and choose **TCP/IP**.



2 Click **Devices**, then **Search Active Devices**. BRAdmin searches for new devices automatically.





3 Double-click the new device.



4 Enter the **IP Address**, **Subnet Mask** and **Gateway**, and then click **OK**.



5 The address information will be saved to the machine.

Note

You can use the BRAdmin Professional utility to set a password. (See the Network User's Guide on the CD-ROM.)

BRAdmin Light configuration utility (For Mac OS® X users)

The Brother BRAdmin Light software is a Java™ application that is designed for the Apple Mac OS® X environment. It supports some of the features of the Windows BRAdmin Professional software. For example, using the BRAdmin Light software, you can change some network settings on Brother's network ready printers and multifunction devices.
The BRAdmin Light software will be installed automatically when you install the MFL-Pro Suite. Please refer to installing the driver and software in this Quick Setup Guide if you have not yet installed the MFL-Pro Suite.
For more information on BRAdmin Light, visit us at http://solutions.brother.com.

Setting your IP address, Subnet Mask and Gateway using BRAdmin Light

Note

If you have a DHCP/BOOTP/RARP server in your network, you don't have to do the following operation. The print server will automatically obtain its own IP address. Make sure that version 1.4.1_07 or later of Java™ client software is installed on your computer.

1 Double-click the **Macintosh HD** icon on your desktop.



2 Choose **Library**, **Printers**, **Brother** and then **Utilities**.



3 Double-click the **BRAdmin Light.jar** file. Run the BRAdmin Light software. BRAdmin Light searches for new devices automatically.



4 Double-click the new device.



5 Enter the **IP Address**, **Subnet Mask** and **Gateway**, and then click **OK**.



6 The address information will be saved to the machine.

How to set the machine's network settings to wireless LAN or wired LAN

To connect your Brother machine to a wireless or wired network you must configure the machine from the machine's control panel for the network type you are using.

For wireless LAN
On your machine, press **Menu**.
Press ▲ or ▼ to choose `LAN` and press **OK**.
Press ▲ or ▼ to choose `Network I/F` and press **OK**.
Press ▲ or ▼ to choose `WLAN` and press **OK**.
The wired network interface will become inactive with this setting.
Press **Stop/Exit**.

It will take about a minute for the LAN menu on the LCD to become available again.

For wired LAN
On your machine, press **Menu**.
Press ▲ or ▼ to choose `LAN` and press **OK**.
Press ▲ or ▼ to choose `Network I/F` and press **OK**.
Press ▲ or ▼ to choose `Wired LAN` and press **OK**.
The wireless network interface will become inactive with this setting.
Press **Stop/Exit**.

Restoring the network settings to factory default

To restore all network settings of the internal Print/Scan server to factory default, please follow the steps below.

1. Make sure the machine is not operating, then disconnect all the cables from the machine (except power cable).
2. Press **Menu**.
3. Press ▲ or ▼ to choose `LAN`.
   Press **OK**.
4. Press ▲ or ▼ to choose `Factory Reset`.
   Press **OK**.
5. Press + to select `Yes`.
6. Press + to select `Yes`.
7. The machine will restart, re-connect cables once this is complete.

Entering Text

Press ▲ or ▼ repeatedly to select a character from the list below:
abcdefghijklmnopqrstuvwxyzABCDEFGHIJKLMNOPQRSTUVWXYZ0123456789
(space)!"#$%&'()✳+,-./:;<=>?@[\]^_`{|}~
Press ◄ or ► repeatedly to move the cursor.

Note

Making corrections

If you entered an incorrect letter and want to change it, press ◄ or ► to position the cursor under the incorrect letter.

Use the ▲ and ▼ keys to change to the correct letter, then press ► repeatedly to move the cursor back to the end of the text.

For example:

64 bit ASCII:	*Uses 5 text characters.* *e.g. "Hello" (this is case sensitive)*
64 bit Hexadecimal:	*Uses 10 digits of hexadecimal data.* *e.g. "71f2234aba"*
128 bit ASCII:	*Uses 13 text characters.* *e.g. "Wirelesscomms" (this is case sensitive)*
128 bit Hexadecimal:	*Uses 26 digits of hexadecimal data.* *e.g. "71f2234ab56cd709e5412aa3ba"*

WPA/WPA2-PSK enables a Wi-Fi® Protected Access Pre-shared key (WPA/WPA2-PSK), which lets the Brother wireless machine associate with access points using TKIP or AES encryption (WPA-Personal). WPA/WPA2-PSK (TKIP or AES) uses a Pre-Shared Key (PSK) that is more than 7 and less than 64 characters in length.
See the Network User's Guide for more details.

Replacement consumables

When the time comes to replace ink cartridges, an error message will be indicated on the LCD. For more information about the ink cartridges for your machine, visit http://solutions.brother.com or contact your local Brother re-seller.

Ink cartridge

Black	Yellow	Cyan	Magenta
LC1000BK	LC1000Y	LC1000C	LC1000M
			

Trademarks
The Brother logo is a registered trademark of Brother Industries, Ltd.
Brother is a registered trademark of Brother Industries, Ltd.
Multi-Function Link is a registered trademark of Brother International Corporation.
Windows and Microsoft are registered trademarks of Microsoft in the U.S. and other countries.
Macintosh and True Type are registered trademarks of Apple Computer, Inc.
PaperPort is a registered trademark of ScanSoft, Inc.
Presto! PageManager is a registered trademark of NewSoft Technology Corporation.
PictBridge is a trademark.
Each company whose software title is mentioned in this manual has a Software License Agreement specific to its proprietary programs.
All other brand and product names mentioned in this manual are trademarks or registered trademarks of their respective companies.

Compilation and Publication
Under the supervision of Brother Industries Ltd., this manual has been compiled and published, covering the latest product descriptions and specifications.
The contents of this manual and the specifications of this product are subject to change without notice.
Brother reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication.
This product is designed for use in a Professional Environment.

Copyright and License
©2006 Brother Industries, Ltd.
This product includes software developed by the following vendors.
©1998-2006 TROY Group, Inc.
©1983-2006 PACIFIC SOFTWORKS, INC.
This product includes the “KASAGO TCP/IP” software developed by Elmic Systems, Inc.
©2006 Devicescape Software, Inc.

LP3688004①
UK
Printed in China