

Read this Quick Setup Guide before using the printer.  
Before you can use the printer, you must set up the hardware and install the driver.

## Step 1




## Setting Up Your Printer

Setting Up  
Your Printer

## Step 2



## Installing the Driver



Installing the Driver

Windows®  
USB

Windows®  
Parallel

Windows®  
Network

Macintosh®  
USB

Macintosh®  
Network



## Setup is Complete!

For  
Administrators

Keep this Quick Setup Guide and supplied CD-ROM in a convenient place so you can use them quickly if you need to.

For the latest driver and to find the best solution for your problem or question, access the Brother Solutions Center directly from the CD-ROM/Driver or go to <http://solutions.brother.com>

# Table of Contents

## ■ Safety Precautions

---

To Use the Printer Safely .....	2
Regulations .....	7

## ■ Getting Started

---

Carton Components .....	9
Control Panel .....	10
Supplied CD-ROM .....	11

## Step 1 Setting Up Your Printer

---

Remove the Packing Tapes and Toner Seal .....	12
Install the Print Head Cartridge .....	13
Load Paper in the Paper Tray .....	14
Print a Printer Settings Page .....	15
Setting Your Language on the Control Panel .....	15

## Step 2 Installing the Driver

---

Windows®	For USB Interface Cable Users .....	17
	For Parallel Interface Cable Users .....	19
	For Network Interface Cable Users .....	21
	For Brother Peer-to-Peer Network Printer Users (LPR) .....	21
	For Brother Peer-to-Peer Network Printer Users (NetBIOS) .....	23
For Network Shared Printer Users .....	25	
Macintosh®	For USB Interface Cable Users .....	27
	For Mac OS® 8.6 to 9.2 Users .....	27
	For Mac OS® X 10.1 / 10.2 Users .....	30
	For Network Interface Cable Users .....	32
	For Mac OS® 8.6 to 9.2 Users .....	32
For Mac OS® X 10.1 / 10.2 Users .....	33	

## ■ For Administrators

---

Setting your IP Address, Subnet Mask and Gateway (Using the Control panel) .....	35
Installing the BRAdmin Professional utility (Windows® Users Only) .....	37
Web BRAdmin .....	37
Print Printer Settings Page .....	37
Factory Default Setting .....	37

## ■ Other Information

---

Shipment of the Printer .....	38
Options .....	39
Consumables .....	39

## ■ Troubleshooting



## User's Guide Chapter 5

# Safety Precautions

## To Use the Printer Safely



To ensure the safe operation of your printer, make sure that you read this section thoroughly before use. This section describes the conventions used in the guide.

 <b>WARNING</b>	Indicates warnings that must be observed to prevent possible personal injury.
 <b>CAUTION</b>	Indicates cautions that must be observed to prevent possible personal injury or material damage.
 High temperature  Flammable  Electrical shock  Finger injury	 This symbol alerts you to procedures that require close attention. Make sure that you read and follow the instructions carefully.
 Prohibited  No naked / open flame  Do not dismantle  Do not touch	 This symbol alerts you to prohibited procedures. Make sure that you read the instructions carefully.
 Hint  Remove the plug  Ground / Earth	 This symbol alerts you to procedures that need to be performed. Make sure that you perform the procedure after reading the instructions carefully.
	<b>Note</b> Indicates notes and useful tips to remember when using the printer.
	<b>User's Guide</b> <b>Network User's Guide</b> Indicates reference to the User's Guide or Network User's Guide which is on the CD-ROM we have supplied.



# Installing and Relocating your Printer

## ⚠ CAUTION


- ⊘ Do not place the printer in a hot, humid, dusty, or poorly ventilated environment. Prolonged exposure to such adverse conditions can cause fire or electric shocks.
- ⊘ Do not place the printer near heaters or volatile, flammable, or combustible materials, such as curtains.
- ! Place the printer on a level, sturdy surface that can withstand the printer's weight. Failure to do so could cause the printer to fall, resulting in injuries.
- ! To prevent injuries, this printer should be lifted by at least two people.
- ! To lift the printer, face the front of the printer and grip the recessed areas at the bottom left and right with both hands. Never try to lift the printer by gripping any other areas. Lifting the printer by gripping other areas can cause the printer to fall, resulting in injuries.



- ! When lifting the printer, get a firm footing and bend your knees to avoid possible injuries to your back.
- ! The printer has ventilation grills on the side and at the back of the machine. Ensure that the printer is installed no less than 150 mm (5.9 in.) from the wall on the right, 100 mm (3.9 in.) from the wall on the left, and 200 mm (7.8 in.) from the wall at the back. A poorly ventilated printer can cause excessive internal heat to build up and result in fire. The diagram below shows the minimum clearances required for normal operation, consumables replacement, and maintenance ensuring that your printer operates at peak performance.



- ⊘ When moving the printer, be sure to unplug the power cord from the AC power outlet/socket. Moving the printer with the power cord connected can damage the power cord, which could result in a fire or an electric shock.
- ⊘ When moving the printer, do not tilt it more than the angles shown in the diagram below. If tilted excessively, the printer may fall, resulting in injuries.



- ! After installing the optional tray module, lock down the brakes of the casters at the front of the tray module. Failure to lock down the brakes can cause the printer to move unexpectedly, resulting in injuries.

## Operating Environment

- Use the printer in a place that meets the following requirements:  
Ambient temperature range of 10 to 32 °C (50.0 to 89.6 °F), relative humidity of 15 to 85% (no condensation)  
When using the printer at an ambient temperature of 32 °C (89.6 °F), the relative humidity should not exceed 65%. When the relative humidity reaches 85%, the ambient temperature should not exceed 28 °C (82.4 °F).
- ⊘ ■ Do not place the printer in a room where there are sudden fluctuations in temperature and do not move the printer from a cold place to a warm humid place. If you do, condensation may occur inside the printer and deteriorate print quality.
- Do not place the printer in direct sunlight, as this may damage the printer.
- When moving the printer, Do not remove the toner cartridges, leave them locked in place. Loose toner can spill inside the printer and deteriorate print quality.
- Do not place the printer directly next to an air conditioner or heater, as this affects the temperature inside the printer and can cause damage.
- Do not use the printer when it is tilted at an angle of more than 5 degrees, as this may result in damage.

## Precautions for Power and Grounded/Earthed Connections

### **WARNING**

- ⚠ Use the printer within the specified power range.  
AC power: 100-127 V AC ± 10% (90V-140V) or 220-240 V AC ± 10% (198V-264V)  
Frequency: 50 ± 3Hz/60 ± 3Hz
- ⚠ Ensure that the AC power cord connector and AC power outlet/socket are free of dust. In a damp environment, a contaminated connector can, over time, draw non-negligible amounts of current that can generate heat and eventually cause fire.
- ⊘ Do not attempt to modify, pull, bend, chafe, or otherwise damage the AC power cord. Do not place objects on the AC power cord. A damaged AC power cord can cause fire or electric shock.
- ⊘ Never touch an AC power cord with wet hands. This constitutes an electric shock hazard.
- ⚠ In the following situations, stop using the printer immediately, turn it off, and disconnect the power cord from the AC power outlet/socket. After that, call your dealer or Brother Customer Service immediately. Continued use of the printer in such situations could result in fire:
  - There is smoke emanating from the printer or the outside of the printer is excessively hot.
  - Unusual noises are coming from the printer.
  - There is water inside the printer.
- ⚠ To prevent fire or electric shocks, connect the AC power cord to a grounded/earthed AC power outlet/socket. For your safety, if in any doubt about the effective grounding/earthing of the power, call a qualified electrician.
- ⚠ If the power cord is broken or insulated wires are exposed, stop using the printer immediately, turn it off, and disconnect the AC power cord from the AC power outlet/socket. After that, call your dealer or Brother Customer Service. Using a damaged cord can cause fire or an electric shock.

### **CAUTION**

- ⊘ Do not plug or unplug the printer when it is on. Unplugging a live connector can deform the plug and cause fire.
- ⚠ When unplugging the printer, grasp the plug instead of the AC power cord. Forcibly pulling the AC power cord can damage it and cause a fire or an electric shock.

 Be sure to turn off and unplug the printer before accessing the interior of the printer for cleaning, maintenance, or troubleshooting. Accessing the interior of a live printer can result in electric shock.

 Once a month, turn off the printer and check the AC power cord for the following:

- The AC power cord is plugged firmly into the AC power outlet.
- The plug is not excessively heated, rusted, or bent.
- The plug and outlet are dust free.
- The cord is not cracked or frayed.
- If you notice any unusual conditions, call your dealer or Brother Customer Service for assistance.

 When the printer is not used over an extended period of time, it is advisable to unplug the printer.

 Switch off the printer before connecting the interface cable or options. Connecting the interface cable or options to a live printer can cause electric shock.

## Radio Interference

This printer may interfere with radio or television reception, causing flickering or distortion. This can be determined by turning the printer off and on. To correct interference, perform one or a combination of the following procedures:

- Move the printer away from a TV and/or radio.
- Reposition the printer, TV and/or radio.
- If the printer, TV and/or radio are plugged in to the same AC power outlet/socket, unplug them, then plug them into different AC power outlets/sockets.
- Reposition the TV and/or radio antennas and cables until the interference stops. For external antennas, consult your local electrician.
- Use coaxial cables with radio and television antennas.

## Operating Precautions

### WARNING

 Do not place any liquid containers such as vases or coffee cups on the printer. Liquids spilt on the printer can cause a fire or electric shock.

 Do not place any metal parts such as staples or clips on the printer. If metal or flammable materials get into the printer, they can short circuit internal components and cause a fire or electric shocks.

 If debris (metal or liquid) gets into the printer, turn off and unplug the printer. After that, call your dealer or Brother Customer Service immediately. Operating a debris-contaminated printer can cause a fire or electric shock.

 Never open or remove printer covers that are secured with screws unless specifically instructed to do so in this guide. High-voltage components can cause electric shocks.

 Do not try to alter the printer's structure or modify any parts. Unauthorized modifications can cause fire.

 This printer complies with the IEC60825 (Class 1) international laser standard. This means that the printer does not present any risk of injury to individuals from laser radiation. Various covers confine the laser radiation to the inside of the printer; hence, users cannot incur injury from the laser under normal operating conditions. Removing covers, unless instructed to do so in this guide, can cause injury from laser radiation.

# ■ Safety Precautions

## CAUTION

-  Never touch an area indicated by a high-temperature warning label (on or near the fuser unit). Touching these areas may result in burns.  
If a sheet of paper is wrapped around the fuser or rollers, do not use excessive force to remove it so as to avoid injuries or burns. Turn off the printer immediately and call your dealer or Brother Customer Service.
-  Do not place any heavy objects on the printer. An off-balance printer can fall over or the heavy object can fall, resulting in injuries.
-  Do not use highly flammable sprays or solvents in or around the printer, as this can result in fire.
-  When removing paper jams, make sure that no pieces of paper are left inside the printer, as this can cause fire.  
If the paper is wrapped around the fuser or roller, or you cannot see the jam that you are trying to clear, do not attempt to remove the paper by yourself, as this may result in injuries or burns. Turn off the printer immediately and call your dealer or Brother Customer Service.
-  Do not place magnetic objects near the safety switch of the printer. Magnets can activate the printer accidentally, resulting in injuries.

## Notes on Handling Consumables

### WARNING

- 
  - Never put a toner cartridge into an open flame. It can explode, resulting in injuries.
  - Never put a transfer roll cartridge into an open flame. It can explode, resulting in injuries.
  - Never put a print head cartridge into an open flame. It can explode, resulting in injuries.

### CAUTION

- Do not open consumables until you are ready to use them. Do not store consumables in the following conditions:
  - Hot or humid areas
  - Near an open flame
  - Exposed to direct sunlight
  - Dusty areas
- Before using consumables, read the instructions and precautions provided with the consumables.
- Administer emergency first aid as follows:
  - Eye Contact: Flush eyes with plenty of water for a minimum of 15 minutes, and seek medical advice.
  - Skin contact: Wash material off skin with plenty of soap and water.
  - Inhalation: remove person to fresh air, and seek medical attention.
  - Ingestion: If toner is swallowed, get immediate medical attention or advice.
- When you remove the transfer roll cartridge from the printer because the waste toner collection box is full, do not attempt to empty the waste toner box and reuse the cartridge, as toner may spill inside the printer and cause damage. Loose toner can spill inside the printer and deteriorate print quality.
- Do not tilt or shake the print head cartridges or transfer roll cartridges when removing them temporarily. Loose toner can spill inside the printer and deteriorate print quality.

# Regulations

## Federal Communications Commission (FCC) Declaration of Conformity (For USA)

Responsible Party: Brother International Corporation  
100 Somerset Corporate Boulevard  
P.O. Box 6911  
Bridgewater, NJ 08807-0911  
USA  
Telephone: (908) 704-1700

declares, that the products

Product name: Laser Printer  
Model number: HL-4200CN  
Product options: All

complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Important

A shielded interface cable should be used in order to ensure compliance with the limits for a Class B digital device. Changes or modifications not expressly approved by Brother Industries, Ltd. could void the user's authority to operate the equipment.

## Industry Canada Compliance Statement (For Canada)

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

## Radio interference (220-240 volt model only)

This printer follows EN55022 (CISPR Publication 22)/Class B.

Before you use this product, make sure that you use a double-shielded interface cable with twisted-pair conductors and that it is marked "IEEE1284 compliant". The cable must not be more than 1.8 metres long.

**brother**

## EC Declaration of Conformity under the R & TTE Directive

### Manufacture

Brother Industries Ltd.,  
15-1, Naeshiro-cho, Mizuho-ku,  
Nagoya 467-8561, Japan

Herewith declare that:

Products description: Laser Printer  
Product Name: HL-4200CN

is in conformity with provisions of the R & TTE Directive (1999/5/EEC 2002) and we declare compliance with the following standards:

R&TTE: EN300330-2 V1.1.1  
EN301489-3 V1.3.1  
CE0682 ①

Safety: EN60950:2000

EMC: EN55022:1998 Class B  
EN55024:1998  
EN61000-3-2:1995 + A14:2000  
EN61000-3-3:1995

Year in which CE marking was first affixed: 2003

Issued by: Brother Industries, Ltd.  
Date: 1 July, 2003  
Place: Nagoya, Japan  
Signature:

*Takashi Maeda*

Takashi Maeda  
Manager  
Quality Management Group  
Quality Management Dept.  
Information & Document Company

## International ENERGY STAR® Compliance Statement

The purpose of the International ENERGY STAR® Program is to promote the development and popularization of energy-efficient office equipment. As an ENERGY STAR® Partner, Brother Industries, Ltd. has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.



## Laser Safety (110 to 120 volt Model Only)

This printer is certified as a Class I laser product under the U.S. Department of Health and Human Services (DHHS) Radiation Performance Standard according to the Radiation Control for Health and Safety Act of 1968. This means that the printer does not produce hazardous laser radiation.

Since radiation emitted inside the printer is completely confined within protective housings and external covers, the laser beam cannot escape from the machine during any phase of user operation.

# Safety Precautions

## FDA Regulations (110 to 120 volt Model Only)

U.S. Food and Drug Administration (FDA) has implemented regulations for laser products manufactured on and after August 2, 1976. Compliance is mandatory for products marketed in the United States. One of the following labels on the back of the printer indicates compliance with the FDA regulations and must be attached to laser products marketed in the United States.

MANUFACTURED:  
Brother Industries, Ltd.,  
15-1 Naeshiro-cho Mizuho-ku Nagoya, 467-8561 Japan  
This product complies with FDA radiation performance standards, 21 CFR subchapter J.

- ☛ Caution: Use of controls, adjustments or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

## IEC 60825 specification (220 to 240 volt model only)

This printer is a Class 1 laser product as defined in IEC 60825 specifications. The label shown below is attached in countries where it is needed.



This printer has a Class 3B laser diode which produces invisible laser radiation in the scanner unit. You should not open the scanner unit under any circumstances.

- ☛ Caution: Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

## For Finland and Sweden LUOKAN 1 LASERLAITE KLASS 1 LASER APPARAT

- ☛ Varoitus! Laitteen käyttäminen muulla kuin tässä käyttöohjeessa mainitulla tavalla saattaa altistaa käyttäjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle.
- ☛ Varning Om apparaten används på annat sätt än i denna Bruksanvisning specificerats, kan användaren utsättas för osynlig laserstrålning, som överskrider gränsen för laserklass 1.

## Internal laser radiation

Maximum radiation power: 10 mW / ch  
Wave length: 760 - 810 nm  
Laser class: Class IIIb  
(Accordance with 21 CFR Part 1040.10)  
Class 3B  
(Accordance with IEC 60825)

## IMPORTANT - For Your Safety

To ensure safe operation the supplied three-pin plug must be inserted only into a standard three-pin power outlet that is properly grounded through the normal household wiring.

Extension cords used with this printer must be three-pin plug type and correctly wired to provide proper grounding. Incorrectly wired extension cords may cause personal injury and equipment damage.

The fact that the equipment operates satisfactorily does not imply that the power is grounded and that the installation is completely safe. For your safety, if in any doubt about the effective grounding of the power, call a qualified electrician.

## Disconnect device

You must install this printer near a power outlet that is easily accessible. In case of an emergency, you must disconnect the power cord from the power outlet to shut off the power completely.

## Caution for LAN connection

Connect this product to a LAN connection that is not subjected to over voltages.

## IT power system (For Norway only)

This product is also designed for an IT power system with phase-to-phase voltage 230V.

## Geräuschemission / Acoustic noise emission (for Germany only)

Lpa < 70 dB (A) DIN 45635-19-01-KL2

## Wiring information (for UK)

### Important






If you need to replace the plug fuse, fit a fuse that is approved by ASTA to BS1362 with the same rating as the original fuse. Always replace the fuse cover. Never use a plug that does not have a cover. Warning - This printer must be earthed.

The wires in the mains lead are coloured in line with the following code:  
Green and Yellow: Earth  
Blue: Neutral  
Brown: Live

If in any doubt, call a qualified electrician.

# Getting Started

## Carton Components

<b>Printer</b>  <b>1</b> Control Panel <b>4</b> Multi-purpose Tray <b>2</b> Top cover <b>5</b> Paper Tray <b>3</b> Front cover	 <b>CD-ROM for Windows®</b> <b>CD-ROM for Macintosh®</b> (including User's Guide)	 <b>Quick Setup Guide</b>
	 <b>AC Power Cord</b>	 <b>Print Head Cartridge</b>
	 <b>Toner Cartridges</b> (Black, Cyan, Magenta and Yellow) * Toner cartridges have already been installed in the printer.	

Carton components may differ from one country to another.



The power cord may be slightly different to the one in the diagram above, depending upon which country you bought the printer in.

Save all packing materials and the printer carton. They should be used when shipping the printer.



- *The interface cable is not a standard accessory. Buy the appropriate interface cable for the interface you intend to use (USB, Parallel or Network).*
- *It's recommended to use a Parallel interface cable or USB interface cable that is not longer than 6 feet (2.0 meters).*
- *For Parallel interface cable use a shielded interface cable that is IEEE 1284-compliant.*
- *Please make sure that you use a Full-Speed USB 2.0 certified cable if your computer uses a Full-Speed USB 2.0 interface.*

## Control Panel



User's Guide Chapter 3.

LED Indicators	
<b>Ready (Green)</b>	Lights when the printer is ready to print. Blinks when the printer is receiving data.
<b>Alarm (Red)</b>	Lights when the printer has a problem that the user can rectify.  <i>User's Guide Chapter 6 to clear the problem.</i>
	Blinks when the printer has a problem that the user cannot rectify.  <i>Note the error code displayed on the LCD, turn off the printer immediately, disconnect the AC power cord from the outlet. Contact your dealer or Brother authorized service representative.</i>
<b>A B</b>	Lights when the printer has paper jams. Open the front cover with the indicated button to clear the jammed paper.

Buttons		
	Print screen mode	Menu screen mode
<b>Menu</b>	Go back to the menu screen mode.	Close the menu screen mode and switch to the print screen mode.
<b>▲ ▼</b>	N/A	Scroll through menus and menu items.
<b>◀ ▶</b>	N/A	◀ Moves the displayed menu one level down. ▶ Moves the displayed menu one level up.
<b>Form Feed / Set</b>	Force the remaining print data to be output.	Select menus and menu items. Moves the displayed menu one level down. Sets the displayed parameter.
<b>Job Cancel / Back</b>	Cancel printing.	Moves the displayed menu one level up.




## Supplied CD-ROM

You can find a variety of information on the CD-ROM.

### Windows®



### Macintosh®



This screen is not supported by Mac OS® 8.6 to 9.2.

#### 1 Brother Solutions Center

The Brother Solutions Center

<http://solutions.brother.com> is your one-stop resource for all your printer needs. Download the latest drivers and utilities for your printers, read the FAQs and troubleshooting tips, or learn about printer solutions.

#### 2 Install Software

Install the printer driver and utilities.

#### 3 Documentation

View the Printer User's Guide and Network User's Guide in PDF format. (Viewer included)

#### 4 Maintenance Tutorial

Instruction movie for printer maintenance.

#### 5 On-Line Registration

Register your product on-line.

#### 6 Color PDF Print Samples

View color samples of printouts in PDF format.




*For visually impaired users, we have prepared an HTML file on the supplied CD-ROM: readme.html. This file can be read by Screen Reader 'text-to-speech' software.*


## 1 Remove the Packing Tapes and Toner Seal




**Do NOT connect the interface cable. You will be prompted to connect the interface cable during the driver installation.**




- 1 Remove all the packing tape.




- 2 Remove the top cover.




- 3 Remove the protective sheet.



- 4 Pull each of the toner seals straight up to remove them.




- 5 Put the top cover back on.






## 2 Install the Print Head Cartridge


- 1 Push up button **A** to open the front cover.



- 2 Push the button to open the paper outlet cover.




- 3 Unpack the print head cartridge.




- 4 Pull the 4 seals firmly to remove them completely.

Check for a circle on the end of the seal.




 If there is no circle on the end of the seal, you can not use this print head cartridge. Contact your dealer for assistance.

- 5 Remove the protective packing.




- 6 Align the rollers of the print head cartridge with the slots, and then gently lower it into the printer.




-  Lowering the cartridge into the printer without correctly aligning the rollers with the slots can damage the cartridge.  
Do not allow the surface covered with a protective sheet to come into contact with anything.

- 7 Pull the protective sheet on the cartridge straight up to remove it.  
**Note:** Do not touch the transfer roller.



- 8 Close the paper outlet cover.  
Close the front cover.



Setting Up  
Your Printer

Windows®  
USB

Windows®  
Parallel

Windows®  
Network

Macintosh®  
USB


Macintosh®  
Network

For  
Administrators


Installing the Driver

## 3 Load Paper in the Paper Tray


- 1 Pull the paper tray out until it stops. Lift up the front of the paper tray slightly and then remove it completely from the printer.




- 2 Remove the protective packing.




- 3 Slide the side paper guides out. Lift the end paper guide and insert it into the slot of the paper size you want to load.




- 4 Load paper in the paper tray. Make sure that all the paper is under the tabs.



- 5 Align the side paper guides with the paper.




- 6 Put the paper tray back in the printer.






## 4 Print a Printer Settings Page


- 1 Connect the AC power cord to the printer, and then plug it into the AC power outlet/ socket.




- 2 Turn on the printer power switch.




- 3 After the printer warms up, the **Ready to Print** message will appear.



Control Panel




- 4 Press **Menu**.



Press **Down Arrow** 3 times.




- 5 Press **Form Feed Set** 3 times.




The printer will now print the printer settings page.


## 5 Setting Your Language on the Control Panel




- 1 Press **Menu**.



- 2 Press **Form Feed Set**.



Press **Down Arrow** 3 times.



- 3 Press **Form Feed Set**.




Press **Up Arrow** or **Down Arrow** to select your language.

Press **Form Feed Set** to accept.



- 4 Press **Menu** to ready to print.



Go to the next page to install the driver.



Follow the instructions on this page for your operating system and interface cable. The screens for Windows® in this Quick Setup Guide are based on Windows® XP. The screens for Mac OS® X in this Quick Setup Guide are based on Mac OS® X 10.1

Windows®



**For USB Interface Cable Users** ..... Go to page 17



**For Parallel Interface Cable Users** ..... Go to page 19



**For Network Interface Cable Users**

- **Brother Peer-to-Peer Network Printer Users (LPR)** ..... Go to page 21
- **Brother Peer-to-Peer Network Printer Users (NetBIOS)** ..... Go to page 23
- **Network Shared Printer Users** ..... Go to page 25

Macintosh®



**For USB Interface Cable Users**

- **Mac OS® 8.6 to 9.2 Users** ..... Go to page 27
- **Mac OS® X 10.1 / 10.2 Users** ..... Go to page 30



**For Network Interface Users**

- **Mac OS® 8.6 to 9.2 Users** ..... Go to page 32
- **Mac OS® X 10.1 / 10.2 Users** ..... Go to page 33

**For Administrators** ..... Go to page 35

Windows®  
USB

Windows®  
Parallel

Windows®  
Network

Macintosh®  
USB

Macintosh®  
Network


For  
Administrators



## For USB Interface Cable Users

### 1. Installing the Driver and Connecting the Printer to Your PC


- 1 Make sure the USB interface cable is **NOT** connected to the printer, and then begin installing the driver. If you have already connected the cable, remove it.



If the **Found New Hardware Wizard** appears on your PC, click the **Cancel** button.



- 2 Insert the CD-ROM for Windows<sup>®</sup> into your CD-ROM drive. The opening screen will appear automatically. Follow the instructions on the screen.



- 3 Click **Install Software** on the Menu screen.




- 4 Depending on the paper size you plan on using, select **Standard Driver - default A4 (Recommended)** or **Standard Driver - default Letter (Recommended)**.




- 5 Click the **Next** button. Follow the instructions on the screen.





- 6 Select **Standard Installation**, and then click the **Next** button.




- 7 Select **Local Printer with USB cable**, and then click the **Next** button.



- 8 When this screen appears, make sure the printer power switch is on. Connect the USB interface cable to your PC, and then connect it to the printer. Click the **Next** button.



- 9 Click the **Finish** button.



 When you register your product on-line, check "On-Line Registration".

**OK!** For Windows® 98 / Me users:  
The Setup is now complete.


**▶▶** For Windows® 2000/XP users:  
Go to "2. Setting Your Printer as the Default Printer".

## 2. Setting Your Printer as the Default Printer (For Windows® 2000/XP Users Only)


- 1 Click **Start** and **Printers and Faxes**.



- 2 Select the **Brother HL-4200CN series** icon.



- 3 From the **File** menu, select **Set as Default printer**.




**OK!** The setup is now complete.




## For Parallel Interface Cable Users

### Connecting the Printer to Your PC and Installing the Driver


- 1 Turn off the printer power switch.



- 2 Connect the parallel interface cable to your PC, and then connect it to your printer.



- 3 Turn on the printer power switch.



 If the **Found New Hardware Wizard** appears on your PC, click the **Cancel** button.



- 4 Insert the CD-ROM for Windows<sup>®</sup> into your CD-ROM drive. The opening screen will appear automatically. Follow the instructions on the screen.



- 5 Click **Install Software** on the Menu screen.




- 6 Depending on the paper size you plan on using, select **Standard Driver - default A4 (Recommended)** or **Standard Driver - default Letter (Recommended)**.




- 7 Click the **Next** button. Follow the instructions on the screen.




- 8 Select **Standard Installation**, and then click the **Next** button.



- 9 Select **Local Printer**, and then click the **Next** button.



- 10 Select the port where your printer is connected, and then click the **Next** button.



- 11 Click the **Finish** button.



When you register your product on-line, check "On-Line Registration".

- OK!** The Setup is now complete.




## For Brother Peer-to-Peer Network Printer Users (LPR)




If you are going to connect the printer to your network, we recommend that you contact your system administrator prior to installation.

### Connecting the Cable and Installing the Driver


- 1 Turn off the printer power switch.



- 2 Connect the network interface cable to the printer, and then connect it to a free port on your hub.



- 3 Turn on the printer power switch.



- 4 Insert the CD-ROM for Windows® into your CD-ROM drive. The opening screen will appear automatically. Follow the instructions on the screen.




- 5 Click **Install Software** on the Menu screen.




- 6 Depending on the paper size you plan on using, select **Standard Driver - default A4 (Recommended)** or **Standard Driver - default Letter (Recommended)**.




- 7 Click the **Next** button. Follow the instructions on the screen.




- 8 Select **Standard Installation**, and then click the **Next** button.



- 9 Select **Brother Peer-to-Peer Network Printer**, and then click the **Next** button.




- 10 Select **Search the network for devices and choose from a list of discovered devices (Recommended)**. Or enter your printer's IP address or its node name. Click the **Next** button.




Contact your Administrator about the printer's IP Address or node name.

- 11 Select your printer and **LPR (Recommended)**, and then click the **Next** button.



- 12 Click the **Finish** button.



When you register your product on-line, check "On-Line Registration".

**OK!** For Windows NT® 4.0 and Windows® 2000/XP users:  
The Setup is now complete.

**OK!** For Windows® 95 / 98 / Me users:  
After your PC has restarted, setup will be complete.



## For Network Interface Cable Users


## For Brother Peer-to-Peer Network Printer Users (NetBIOS)




If you are going to connect the printer to your network, we recommend that you contact your system administrator prior to installation.

### Connecting the Cable and Installing the Driver


- 1 Turn off the printer power switch.



- 2 Connect the network interface cable to the printer, and then connect it to a free port on your hub.



- 3 Turn on the printer power switch.



- 4 Insert the CD-ROM for Windows® into your CD-ROM drive. The opening screen will appear automatically. Follow the instructions on the screen.



- 5 Click **Install Software** on the Menu screen.




- 6 Depending on the paper size you plan on using, select **Standard Driver - default A4 (Recommended)** or **Standard Driver - default Letter (Recommended)**.




- 7 Click the **Next** button. Follow the instructions on the screen.




- 8 Select **Standard Installation**, and then click the **Next** button.




- 9 Select **Brother Peer-to-Peer Network Printer**, and then click the **Next** button.



- 10 Select **Search the network for devices and choose from a list of discovered devices (Recommended)**. Click the **Next** button.



- 11 Select your printer and **NetBIOS**, and then click the **Next** button.



- 12 Click the **Finish** button.



When you register your product on-line, check "On-Line Registration".

**OK!** For Windows NT® 4.0 and Windows® 2000/XP users:  
The Setup is now complete.

**OK!** For Windows® 95 / 98 / Me users:  
After your PC has restarted, setup will be complete.



## For Network Interface Cable Users


### For Network Shared Printer Users




If you are going to connect the printer to your network, we recommended that you contact your system administrator prior to installation.

### Connecting the Cable, Installing the Driver and Selecting the Appropriate Printer Queue or 'Share name'


- 1 Turn off the printer power switch.



- 2 Connect the network interface cable to the printer, and then connect it to a free port on your hub.



- 3 Turn on the printer power switch.



- 4 Insert the CD-ROM for Windows® into your CD-ROM drive. The opening screen will appear automatically. Follow the instructions on the screen.



- 5 Click **Install Software** on the Menu screen.




- 6 Depending on the paper size you plan on using, select **Standard Driver - default A4 (Recommended)** or **Standard Driver - default Letter (Recommended)**.




- 7 Click the **Next** button. Follow the instructions on the screen.



- 8 Select **Standard Installation**, and then click the **Next** button.



- 9 Select **Network Shared Printer**, and then click the **Next** button.



- 10 Select your printer's queue, and then click the **OK** button.



Contact your Administrator about the printer's queue.

- 11 Click the **Finish** button.



When you register your product on-line, check "On-Line Registration".

- OK!** The setup is now complete.


## For USB Interface Cable Users

### For Mac OS<sup>®</sup> 8.6 to 9.2 Users

#### 1. Set the Adobe Protocol



1 Press **Menu**.



2 Press **Form Feed** 5 times.



3 Press **Form Feed**.




4 Press **Form Feed**.



5 Press **Form Feed**.




6 Press **Form Feed**.



3 seconds later, an asterisk appears.

7 Restart the printer.



#### 2. Connecting the Printer to Your Macintosh & Installing the PPD File and Adobe PS Driver


1 Make sure the printer power switch is on.




2 Connect the USB interface cable to your Macintosh<sup>®</sup>, and then connect it to the printer.



*Do not connect the USB cable to the keyboard USB Port or a non-powered USB Hub.*




3 Insert the CD-ROM for Macintosh<sup>®</sup> into your CD-ROM drive. Open the **Mac OS 9** folder.




4 Open your language folder.




- 5 Double-click the **PPD Installer** icon to install the PPD file.  
Follow the instructions on the screen.




- 6 Double-click the **AdobePS Installer** icon to install the PS driver.  
Follow the instructions on the screen.




- 7 Open the **Macintosh HD** icon.




- 8 Open the **AdobePS Components** folder.




- 9 Open the **Desktop Printer Utility** icon.




- 10 Select **Printer (USB)**, and then click the **OK** button.



- 11 Click the **Change...** button in **PostScript™ Printer Description (PPD) file**.  
Select **Brother HL-4200CN**, and then click the **Select** button.



- 12 Click the **Change...** button in **USB Printer Selection**.  
Select **HL-4200CN**, and then click the **OK** button.




Continue to  
the next page




## For USB Interface Cable Users

### For Mac OS<sup>®</sup> 8.6 to 9.2 Users

- 13 Click the **Create...** button.




- 14 Enter your printer name (HL-4200CN), and then click the **Save** button.




- 15 Select **Quit** from the **File** menu.



- 16 Click the **HL-4200CN** icon on the Desktop.



- 17 Select **Set Default Printer** from the **Printing** menu.



- OK!** The setup is now complete.




## For USB Interface Cable Users

### For Mac OS® X 10.1 / 10.2 Users

#### Connecting the Printer to Your Macintosh & Installing the Adobe PostScript 3 PPD File


- 1 Make sure the printer power switch is on.



- 2 Connect the USB interface cable to your Macintosh, and then connect it to the printer.




*Do not connect the USB cable to the keyboard USB Port or a non-powered USB Hub.*




- 3 Insert the CD-ROM for Macintosh® into your CD-ROM drive. Open the **Start Here OS X** icon. Follow the instructions on the screen.



- 4 Click **Install Software** on the Menu screen. Follow the instructions on the screen.



- 5 Select **Applications** from the **Go** menu.



- 6 Open the **Utilities** folder.



- 7 Open the **Print Center** icon.




Continue to  
the next page



## For USB Interface Cable Users

### For Mac OS<sup>®</sup> X 10.1 / 10.2 Users

- 8 Click the **Add Printer...** button.




- 9 Select **USB**.



- 10 Select **HL-4200CN series**, and then click the **Add** button.



- 11 Select **Quit Print Center** from the **Print Center** menu.



- OK!** The setup is now complete.



## For Network Interface Cable Users


### For Mac OS® 8.6 to 9.2 Users

#### Connecting the Printer to Your Network & Installing the PPD File and Adobe PS Driver

- 1 Turn off the printer power switch.




- 2 Connect the network interface cable to the printer, and then connect it to a free port on your hub.




- 3 Turn on the printer power switch.



- 4 Insert the CD-ROM for Macintosh® into your CD-ROM drive. Open the **Mac OS 9** folder. Open your language folder.



- 5 Double-click the **PPD Installer** icon to install the PPD file. Follow the instructions on the screen.




- 6 Double-click the **AdobePS Installer** icon to install the PS driver. Follow the instructions on the screen.



- 7 Open the **Chooser** from the Apple Menu.



- 8 Click the **AdobePS** icon, and then select **BRN\_xxxxxx\_P1\_AT**.<sup>\*1</sup> Click the **Create** button. Close the **Chooser**.



<sup>\*1</sup> xxxxxx are the last six digits of the Ethernet address.



Network User's Guide Chapter 7.

**OK!** The setup is now complete.




## For Network Interface Cable Users


### For Mac OS<sup>®</sup> X 10.1 / 10.2 Users

#### Connecting the Printer to Your Network & Installing the Adobe PostScript 3 PPD File


- 1 Turn off the printer power switch.



- 2 Connect the network interface cable to the printer, and then connect it to a free port on your hub.



- 3 Turn on the printer power switch.




- 4 Insert the CD-ROM for Macintosh<sup>®</sup> into the CD-ROM drive. Open the **Start Here OS X** folder. Follow the instructions on the screen.



- 5 Click **Install Software** on the Menu screen. Follow the instructions on the screen.





- 6 Select **Applications** from the **Go** menu.




- 7 Open the **Utilities** folder.




- 8 Open the **Print Center** icon.




9 Click the **Add Printer...** button.



10 Select **AppleTalk**.



11 Select **BRN\_XXXXXX\_P1\_AT\*1**, and then click the **Add** button.




\*1 xxxxxx are the last six digits of the Ethernet address.



Network User's Guide Chapter 7.

12 Select **Quit Print Center** from the **Print Center** menu.



OK! The setup is now complete.

## Setting your IP Address, Subnet Mask and Gateway (Using the Control panel)



Your printer is configured to receive an IP address, Subnet mask and Gateway address from a DHCP server. If you do not use a DHCP server follow the steps below.

### Setting the IP Address Acquisition Method to Control Panel.

- 1 Press  .  

- 2 Press  4 times.  


- 3 Press  .  

- 4 Press  .  

- 5 Press  .  

- 6 Press  .  

- 7 Press  .  

- 8 Press  .  


3 seconds later, an asterisk appears.


- 9 Press  .  


### Setting Your Printer IP Address.

Continued from the previous step.


- 10 Press  .  

- 11 Press  .  

- 12 Using  or , set the desired value (for example 192).  

- 13 Press  and move the cursor to the next value.  

- 14 Repeat Steps 12 and 13 to finish setting you IP address.  

- 15 Press  .  


3 seconds later, an asterisk appears.


- 16 Press  .  


# Setting your IP Address, Subnet Mask and Gateway (Using the Control panel)

## Setting Your Subnet Mask.

Continued from the previous step.

TCP/IP  
IP Address

17 Press .

TCP/IP  
Subnet Mask

18 Press  .

Subnet Mask  
000.000.000.000

19 Set your subnet mask in the same way as the IP address.

Reboot System  
to take effect

3 seconds later, an asterisk appears.

IP Address  
255.255.255.000\*

20 Press  .

TCP/IP  
Subnet Mask

If you want to set your Gateway address:  
Go to 21.

If you do not want to set your Gateway address:  
Go to 24.

## Setting Your Gateway address.

Continued from the previous step.

TCP/IP  
Subnet Mask

21 Press .

TCP/IP  
Gateway Address

22 Press  .

Gateway Address  
000.000.000.000


23 Set your gateway address in the same way as the IP address.

Reboot System  
to take effect

3 seconds later, an asterisk appears.

Gateway Address  
192.168.001.254\*

24 Restart the printer.



Setting Up  
Your Printer

Windows®  
USB

Windows®  
Parallel

Installing the Driver

Windows®  
Network

Macintosh®  
USB

Macintosh®  
Network

For  
Administrators

## Installing the BRAdmin Professional utility (Windows® Users Only)

The BRAdmin Professional utility is designed to manage your Brother network connected devices. The BRAdmin Professional utility can also be used to manage devices from other manufacturers whose products support SNMP (Simple Network Management Protocol). For more information on BRAdmin Professional go to <http://solutions.brother.com>

- 1 Insert the CD-ROM for Windows® into your CD-ROM drive. The opening screen will appear automatically. Follow the instructions on the screen.



- 2 Click the **Install Software** icon on the Menu screen.



- 3 Click **For Administrators**, and then click **BRAdmin Professional**.



The default password for the print server is 'access'. You can use the BRAdmin Professional software or a web browser to change this password.

## Web BRAdmin

Brother has also developed Web BRAdmin, an enterprise network software utility that enables management of Brother and other SNMP compliant devices in larger LAN/WAN environments.

This software is Web server based and requires the installation of Microsoft's Internet Information Server and Sun's Java client software. To learn more about the Web BRAdmin software or to download it, please go to <http://solutions.brother.com/webbradmin>

## Print Printer Settings Page

To print a printer settings page, see "Print a Printer Settings Page" on page 15.

## Factory Default Setting

If you wish to reset the print server back to its default factory settings (resetting all information such as the password and IP address information), reset the Init NVM setting from the Maintenance menu by using the Control panel.

## Shipment of the Printer

If for any reason you must ship your Printer, carefully package the Printer to avoid any damage during transit. It is recommended that you save and use the original packaging. The Printer should also be adequately insured with the carrier.




**When shipping the Printer, Do not remove the TONER CARTRIDGES, leave them locked in place. BUT the PRINT HEAD CARTRIDGE must be removed from the Printer and placed in the plastic bag. Failure to remove the unit and place it in the plastic bag during shipping will cause severe damage to the Printer and will VOID THE WARRANTY.**


- 1 Turn off the printer power switch, and then unplug the AC power cord.



- 2 Remove the paper from the paper tray and the print head cartridge from the printer. Place it in the plastic bag and seal the bag completely. **DO NOT REMOVE THE TONER CARTRIDGES, LEAVE THEM LOCKED IN PLACE.**



- 3 Re-pack the printer.



### Trademarks

The Brother logo is a registered trademark of Brother Industries, Ltd.  
Windows® and Windows NT® are registered trademarks of Microsoft Corporation in the U.S and other countries.  
Apple Macintosh, iMac, LaserWriter and AppleTalk are registered trademarks of Apple Computer, Inc.  
Hewlett-Packard, HP, PCL 5e, PCL 6, PCL, HP/UX, JetDirect and JetAdmin are trademarks of Hewlett-Packard Company.  
UNIX is a trademark of UNIX Systems Laboratories.  
Adobe, Adobe logo, Acrobat, PostScript and PostScript3 are trademarks of Adobe Systems Incorporated.  
Netware is a trademark of Novell, Inc.  
ENERGY STAR is a U.S. registered mark.  
Centronics is a trademark of Genicom Corporation.  
This printer contains UFST and Micro Type from Agfa Division.  
PANTONE Colors generated by the HL-4200CN are four- and /or three-color process simulations and may not match PANTONE-identified solid color standards. Use current PANTONE Color Reference Manuals for accurate color.  
PANTONE Color simulations are only obtainable on this product when driven by qualified Pantone-licensed software packages. Contact Pantone Inc. for a current list of qualified licensees.  
© 2003 TROY XCD Inc.  
© 2003 PACIFIC SOFTWARES INC  
All other brand and product names mentioned in this User's Guide are registered

### Compilation and Publication





Under the supervision of Brother Industries Ltd., this manual has been compiled and published, covering the latest product descriptions and specifications.  
The contents of this manual and the specifications of this product are subject to change without notice.  
Brother reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication.  
This product is designed for use in a Professional Environment.

## Options

The printer has the following optional accessories. You can increase the capabilities of the printer with these items.




*User's Guide Appendixes.*





1 Tray Module	2 Tray Module	Hard Disk	Memory Expansion
<b>LT-41CL</b>	<b>LT-42CL</b>	<b>HD-41CL</b>	
			
You can install an up to 500 sheet tray unit.	You can install an up to 1000 (2x500) sheet tray unit.	Reduce the time taken to print multiple copies of a document. Analyze printer usage by user.	You can expand the memory up to 320 MB by installing (144-pin DIMM) memory modules.

## Consumables

When the time comes to replace consumables, an error messages will appear on the LCD panel.



*User's Guide Chapter 7.*

Toner Cartridge	Print Head Cartridge	Transfer Roll Cartridge	Fuser unit
<b>TN-12BK/TN-12C/ TN-12M/TN-12Y</b>	<b>PH-12CL</b>	<b>TR-11CL</b>	<b>FP-12CL</b>
			

**brother**<sup>®</sup>

LM0939001