
HL-4040CN HL-4050CDN



Before you can use the printer, you must set up the hardware and install the driver. Please read this 'Quick Setup Guide' for proper set up and installation instructions.

STEP 1

Setting Up the Machine



STEP 2

Installing the Printer Driver

Setup is Complete!



How to use the printer, see the User's Guide in the CD-ROM.

Keep this 'Quick Setup Guide' and the supplied CD-ROM in a convenient place for quick and easy reference at all times.



Warning	Electrical Hazard	Hot Surface	Caution
Warnings tell you what to do to prevent possible personal injury.	Electrical Hazard icons alert you to a possible electrical shock.	Hot Surface icons warn you not to touch machine parts that are hot.	Cautions specify procedures you must follow or avoid to prevent possible damage to the printer or other objects.
Marcoper Setup	Note	User's Guide Network User's Guide	
Improper Setup icons alert you to devices and operations that are not compatible with the printer.	Notes tell you how you should respond to a situation that may arise or give tips about how the current operation works with other features.	Indicates reference to the User's Guide or Network User's Guide which is on the CD-ROM we have supplied.	

Safety Precautions	4
To Use the Printer Safely	4
Regulations	5
Getting Started	
What is in the box?	7
Control panel	
Supplied CD-ROM	
STEP 1—Setting Up the Machine	
Put the CD-ROM into the CD-ROM drive	10
Removing the packing materials from the printer	
Installing the toner cartridges	
Loading paper in the paper tray	
Printing a test page	
Setting your language on the control panel	
STEP 2—Installing the Printer Driver	
<u> </u>	
Windows [®]	
	4.0
For USB interface cable users	
For parallel interface cable users	
For Peer-to-Peer network printer users	
For shared network printer users	
·	
Macintosh [®]	
For USB interface cable users	21
For network interface cable users	22
Other Information	
Shipment of the printer	24
Troubleshooting	

Q Chapter 7 of the User's Guide on the CD-ROM

3




To Use the Printer Safely

Λ

Warning



There are high voltage electrodes inside the printer. Before you clean the inside of the printer, make sure that you have turned off the power switch and unplugged the printer from the AC power outlet.






DO NOT handle the plug with wet hands. Doing this might cause an electrical shock.





The fuser unit becomes extremely hot during operation. Wait until it has cooled down sufficiently before replacing consumable items. DO NOT remove or damage the caution labels located on or around the fuser.





DO NOT use flammable substances or any type of spray to clean the inside or outside of the machine. Doing this may cause a fire or electrical shock. Refer to the User's Guide for how to clean the machine.





DO NOT use a vacuum cleaner to clean up scattered toner. Doing this might cause the toner dust to ignite inside the vacuum cleaner, potentially starting a fire. Please carefully clean the toner dust with a dry, lint-free cloth and dispose of it according to local regulations.




If the printer becomes hot, blows smoke, or generates obscure odor, immediately turn off the power switch and unplug the printer from the AC power outlet. Call your Brother dealer or Brother Customer Service.



If metal objects, water or other liquids get inside the printer, immediately turn off the power switch and unplug the printer from the AC power outlet. Call your Brother dealer or Brother Customer Service.



This printer is heavy and weighs approximately 64.2 lb. (29.1 kg). To prevent injuries use at least two people to lift the printer. Be careful not to pinch your fingers when you put the printer back down.





Regulations

Important

A shielded interface cable should be used in order to ensure compliance with the limits for a Class B digital device.

Changes or modifications not expressly approved by Brother Industries, Ltd. could void the user's authority to operate the equipment.

Radio interference (220-240 volt model only)

This printer follows EN55022 (CISPR Publication 22)/Class B.

Before you use this product, make sure that you use one of the following interface cables.

- A shielded parallel interface cable with twisted-pair conductors and that it is marked "IEEE 1284 compliant".
- 2 A USB cable.

The cable must not be more than 2 meters long.

EC Declaration of Conformity



EC Declaration of Conformity

Manufacturer Brother Industries Ltd.,

15-1, Naeshiro-cho, Mizuho-ku, Nagoya 467-8561, Japan

<u>Plant</u> Brother Technology (Shenzhen) Ltd., NO6 Gold Garden Ind. Nanling Buji, Longgang, Shenzhen, China

Products description : Laser Printer
Product Name : HL-4040CN, HL-4050CDN

Model Number : HL-40C

are in conformity with provisions of the Directives applied : Low Voltage Directive 73/23/EEC (as amended by 93/68/EEC) and the Electromagnetic Compatibility Directive 89/336/EEC (as amended by 91/263/EEC and 92/31/EEC and 93/68/EEC).

Harmonized standards applied

Safety EN60950-1:2001+A11: 2004

EMC EN55022: 1998 + A1: 2000 + A2: 2003 Class B EN55024: 1998 + A1: 2001 + A2: 2003 EN61000-3-2: 2000 EN61000-3-2: 1995 + A1: 2001

Year in which CE marking was first affixed : 2006

Issued by : Brother Industries Ltd. Date : 1st September, 2006 : Nagoya, Japan

Signature

Junji Shiota General Manager Quality Management Dept. Printing & Solutions Company

International ENERGY STAR® Compliance Statement

The purpose of the International ENERGY STAR® Program is to promote the development and popularization of energy-efficient office equipment. As an ENERGY STAR® Partner, Brother Industries, Ltd. has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.



IEC 60825-1 specification (220 to 240 volt model only)

This printer is a Class 1 laser product as defined in IEC 60825-1+A2: 2001 specifications. The label shown below is attached in countries where it is needed.



This printer has a Class 3B laser diode which produces invisible laser radiation in the laser unit. You should not open the laser unit under any circumstances.



Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Internal laser radiation

Maximum radiation power: 25 mW
Wave length: 780 - 800 nm
Laser class: Class 3B

IMPORTANT - For Your Safety

To ensure safe operation, the supplied three-pin plug must be inserted only into a standard three-pin power outlet that is properly grounded through the normal household wiring.

Extension cords used with this printer must be threepin plug type and correctly wired to provide proper grounding. Incorrectly wired extension cords may cause personal injury and equipment damage. The fact that the equipment operates satisfactorily does not imply that the power is grounded and that the installation is completely safe. For your safety, if in any doubt about the effective grounding of the power, call a qualified electrician.

This product should be connected to an AC power source within the range indicated on the rating label. DO NOT connect it to a DC power source. If you are not sure, contact a qualified electrician.

Disconnect device

You must install this printer near a power outlet that is easily accessible. In case of an emergency, you must disconnect the power cord from the power outlet to shut off the power completely.

Caution for LAN connection

Connect this product to a LAN connection that is not subjected to over voltages.

Warning - This printer must be earthed.

The wires in the mains lead are coloured in line with the following code:

Green and Yellow: Earth
Blue: Neutral
Brown: Live


If in any doubt, call a qualified electrician.



What is in the box?


Carton components may vary from one country to another.

Save all packing materials and the printer carton in case for any reason you must ship your printer.



- 1 Front cover release button
- 2 Control panel 1
- 3 USB direct interface
- 4 Front cover

- 5 Paper tray
- 6 Power switch
- 7 Face-down output tray
- 8 Face-down output tray support flap (Support flap)
- 9 Multi -purpose tray (MP tray)
- You can adjust the angle of the LCD display by tilting it up or down.



The interface cable is not a standard accessory. Buy the appropriate cable for the interface you are going to use.

■ USB cable

Do not use a USB interface cable that is longer than 6 feet (2.0 meters).


Do not connect the USB cable to a non-powered hub or a Macintosh[®] keyboard.

Make sure that you connect it to the USB connector of your computer.

- Parallel cable (For HL-4050CDN users)
 - Do not use a parallel interface cable that is longer than 6 feet (2.0 meters).
 - Use a shielded interface cable that is IEEE 1284-compliant.
- Network cable

Use a straight-through Category5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.

Control panel



1 Menu buttons

+

Scroll backward through menus and the available options.

— -

Scroll forward through menus and the available options.

= OK

Choose the control panel menu.

Select the chosen menus and settings.

■ Back

Go back one level in the menu structure.

2 Reprint button

Choose the reprint menu.

3 Go button

Clear error messages.

Pause and continue printing.

4 Cancel button

Stop and cancel the print operation in progress.

Exit from a menu (control panel menu, reprint menu or Direct Print menu)

5 Direct Print LED: Blue

■ On

USB flash memory is inserted into the USB direct interface.

Off

USB flash memory is not inserted into the USB direct interface.

Direct Print button

Switch to Direct Print mode when USB flash memory is inserted into the USB direct interface.

6 LCD back light

■ Off

The printer is off or in sleep status.

■ Green (General)

Ready to print / Printing / Warming up

■ Red (Error)

There is a problem with the printer.

■ Orange (Setting)

Choose a menu (control panel menu, reprint menu or Direct Print menu) or Pause

LCD messages

The message on the LCD shows the current printer status during normal operation.

The \blacksquare marks indicate the status of the toner in the toner cartridges. When the \blacksquare mark blinks (\square), the indicated toner is nearly empty. When toner becomes empty, the \blacksquare indicator disappears completely.

7 Data LED: Yellow

■ On

Data is in the printer memory.

Blinking

Receiving / processing data

■ Off

No remaining data in the memory.

 \mathbb{Q}

For the control panel details, see Chapter 4 of the User's Guide on the CD-ROM.



Supplied CD-ROM

You can find a variety of information on the CD-ROM.

Windows[®]





Initial Setup

Instructional movie for printer setup.



Install Printer Driver

Install the printer driver.



lnstall Other Drivers or Utilities

Install optional drivers, utilities and Network management tools.



Documentation

View the Printer User's Guide and Network User's Guide in HTML format.

You can also view the manuals in PDF format by accessing the Brother Solutions Center.

The User's Guide and Network User's Guide in HTML format will be installed automatically when you install the driver. Click the **Start** button, **All Programs** ¹, your printer (Brother HL-4050CDN), and then User's Guide. If you do not want to install the User's Guide, choose Custom setup from Install Printer Driver, and uncheck User's Guides in HTML format when you install the driver.

Programs for Windows® 2000 users



On-Line Registration

Register your product on-line.



Brother Solutions Center

The Brother Solutions Center


(http://solutions.brother.com) is a one-stop resource for all your printer support needs. Download the latest drivers and utilities for your printers, read FAQs and troubleshooting tips, or learn about printer solutions.



Supplies Information

Visit our web site for original/genuine Brother supplies at http://www.brother.com/original/

Macintosh[®]







Initial Setup

Instructional movie for printer setup.



🗐 Install Printer Driver

Install the printer driver.



Documentation

View the Printer User's Guide and Network User's Guide in HTML format.

You can also view the User's Guide in PDF format by accessing the Brother Solutions Center.



On-Line Registration

Register your product on-line.



Brother Solutions Center

The Brother Solutions Center

(http://solutions.brother.com) is a one-stop resource for all your printer support needs. Download the latest drivers and utilities for your printers, read FAQs and troubleshooting tips, or learn about printer solutions.



Supplies Information

Visit our web site for original/genuine Brother supplies at http://www.brother.com/original/



For visually impaired users, we have prepared an HTML file on the supplied CD-ROM: readme.html. This file can be read by Screen Reader 'text-tospeech' software.



Put the CD-ROM into the CD-ROM drive

For Windows® users

Name of the last o

DO NOT connect the interface cable. Connecting the interface cable is done when installing the driver.



Turn on your computer. (You must be logged on with Administrator rights.) Put the supplied CD-ROM into your CD-ROM drive. The opening screen will appear automatically. Choose your printer model and the language.



Click Initial Setup on the menu screen.



You can view the initial setup instructions and follow along with the steps on the next page.




For Macintosh® users

Name of the last o

DO NOT connect the interface cable. Connecting the interface cable is done when installing the driver.



Turn on your Macintosh[®]. Put the supplied CD-ROM into your CD-ROM drive, and then double-click the **HL4040_4050** icon on your desktop. Double-click the **Start Here** icon. Follow the on-screen instructions.



Click Initial Setup on the menu screen.



You can view the initial setup instructions and follow along with the steps on the next page.



Setting Up the Machine

Removing the packing materials from the printer


Important

Save all packing material and the carton in case you have to ship your machine.


Improper Setup
DO NOT plug in the AC power cord yet.




Press the front cover release button and open the front cover.




Remove the 4 pieces of orange packing material as shown in the illustration below.



Hold the green handle of the drum unit. Lift the drum unit up and then pull it out until it stops.




Remove the orange packing material as shown in the illustration below.



P1 Setting Up the Machine

Installing the toner cartridges


Unpack the toner cartridges and rock each toner cartridge 5 to 6 times.



Remove the protective cover.




Hold the handle of the toner cartridge and slide it into the drum unit. Make sure that you match the toner cartridge color to the same color label on the drum unit, and make sure that you fold down the toner cartridge handle (1) once the toner cartridge is in place.




- 1 **C** Cyan
- 2 M Magenta
- 3 Y Yellow
- 4 K Black
- Repeat steps 1 through 3 for the remaining toner cartridges.


5 Put the drum unit back into the printer.




6 Close the front cover of the printer.



- Loading paper in the paper tray
- Pull the paper tray completely out of the printer.




While pressing the green paper-guide release lever (1), slide the paper guides to fit the paper size. Make sure that the guides are firmly in the slots.




Setting Up the Machine

Fan the stack of paper well to avoid paper jams and misfeeds.




Put paper in the paper tray. Make sure that the paper is flat in the tray and below the maximum paper mark.



Put the paper tray firmly back into the printer.


Make sure that it is completely inserted into the printer.




- 5 Printing a test page
- Improper Setup
 DO NOT connect the interface cable yet.




1 Lift the LCD display and adjust it for the best viewing angle.




Unfold the support flap.



Make sure that the printer power switch is off. Remove the label covering the AC power inlet.



4 Connect the AC power cord to the printer.



STEP 1


Setting Up the Machine

5 Plug the AC power cord into an AC power outlet. Turn on the printer power switch.






6 After the printer has finished warming up, the LCD shows Ready.



Press Go. The printer prints a test page. Check that the test page has printed correctly.





- If you press Reprint, the printer prints a duplex test page. (For HL-4050CDN)
- This function will not be available after the first print job you send from your computer.

6 Setting your language on the control panel



Press the + or – button until the LCD shows
General Setup.

Press OK.

Select **∆V** or OK General Setup

2 Press **OK** again.

General Setup Local Language

Press the + or – button to choose your language. Press **OK** to accept.

Local Language English

STEP 2 Installing the Printer Driver

Follow the instructions on this page for your operating system and interface. For the latest drivers, documentation, and to find the best solution for your problem, access the Brother Solution Center directly from the CD-ROM / Driver or visit http://solutions.brother.com.

Windows®







Macintosh®






For network interface cable users



For USB interface cable users




If the Found New Hardware Wizard appears on your computer, click Cancel.



Installing the driver and connecting the printer to your computer

Make sure the USB interface cable is NOT connected to the printer, and then begin installing the driver. If you have already connected the cable, remove it.



2 Click Install Printer Driver on the menu screen.




Click USB cable users.




 For Windows Vista™, when the User Account Control screen appears, click Continue.



- If you want to install the PS driver (Brother's BR-Script Driver), choose Custom setup and then follow the on-screen instructions. When the Select Components screen appears, check PS(PostScript Emulation) Driver, and then continue following the on-screen instructions.
- 4 When the License Agreement window appears, click Yes if you agree to the License Agreement.
- 5 When this screen appears, make sure the printer power switch is on. Connect the USB interface cable to your computer, and then connect it to the printer. Click Next.





Click Finish.



- If you want to register your product on-line, check On-Line Registration.
- If you do not want to set your printer as Default printer, uncheck Set as Default Printer.




Setup is now complete.



For parallel interface cable users



If the **Found New Hardware Wizard** appears on your computer, click **Cancel**.



Installing the driver and connecting the printer to your computer


Click Install Printer Driver on the menu screen.



Click Parallel cable users.



 For Windows Vista[™], when the User Account Control screen appears, click Continue.



- If you want to install the PS driver (Brother's BR-Script Driver), choose Custom setup and then follow the on-screen instructions. When the Select Components screen appears, check PS(PostScript Emulation) Driver, and then continue following the on-screen instructions.
- When the License Agreement window appears, click **Yes** if you agree to the License Agreement.
- 4 Click Finish.



 If you want to register your product on-line, check On-Line Registration.

- If you do not want to set your printer as Default printer, uncheck Set as Default Printer.
- 5 Turn off the printer power switch.



Connect the parallel interface cable to your computer, and then connect it to your printer.



Turn on the printer power switch.




OKI Setup is now complete.



For network interface cable users

For Peer-to-Peer network printer users



- 1 Router
- 2 Network printer



- If you are going to connect the printer to your network, we recommend that you contact your system administrator prior to installation or see the Network User's Guide on the CD-ROM.
- If you are using Personal Firewall software (e.g. Windows Firewall), disable it. Once you are sure that you can print, restart your Personal Firewall software.

Connecting the printer to your network and installing the driver

Click Install Printer Driver on the menu screen.



Click Network cable users.




 For Windows Vista[™], when the User Account Control screen appears, click Continue.



- If you want to install the PS driver (Brother's BR-Script Driver), choose Custom setup and then follow the on-screen instructions. When the Select Components screen appears, check PS(PostScript Emulation) Driver, and then continue following the on-screen instructions.
- Turn off the printer power switch.




Connect the network interface cable to the printer, and then connect it to a free port on your hub.




5 Turn on the printer power switch.



- When the License Agreement window appears, click **Yes** if you agree to the License Agreement.
- Choose Brother Peer-to-Peer Network Printer, and then click Next.




Choose Search the network for devices and choose from a list of discovered devices (Recommended). Or enter your printer's IP address or its node name. Click Next.





Contact your administrator if you do not know the printer's IP address or node name.

9 Choose your printer, and then click **Next**.




10 Click Finish.



- If you want to register your product on-line, check On-Line Registration.
- If you do not want to set your printer as Default printer, uncheck Set as Default Printer.

For shared network printer users



- Network Shared
- 2 Also known as "Server" or "Printer server"
- 3 Printer
- 4 TCP/IP, USB or Parallel



If you are going to connect to a shared printer on your network, we recommend that you ask your system administrator about the queue or share name for the printer prior to installation. Installing the driver and choosing the correct printer queue or share name

Click Install Printer Driver on the menu screen.



2 Click Network cable users.



 For Windows Vista[™], when the User Account Control screen appears, click Continue.



 If you want to install the PS driver (Brother's BR-Script Driver), choose Custom setup and then follow the on-screen instructions. When the Select Components screen appears, check PS(PostScript Emulation) Driver, and then continue following the on-screen instructions.

- When the License Agreement window appears, click **Yes** if you agree to the License Agreement.
- Choose Network Shared Printer, and then click Next.



Choose your printer's queue, and then click







Contact your administrator if you do not know the location or the name of the printer in the network.

6 Click Finish.



- If you want to register your product on-line, check On-Line Registration.
- If you do not want to set your printer as Default printer, uncheck Set as Default Printer.




Setup is now complete.



For USB interface cable users

Connecting the printer to your $Macintosh^{@}$ and installing the driver

Connect the USB interface cable to your Macintosh®, and then connect it to the printer.



Name of the last o

DO NOT connect the printer to a USB port on a keyboard or a non-powered USB hub.

Make sure the printer power switch is on.



Click Install Printer Driver on the menu screen.



Click USB cable users and follow the on-screen instructions. Then, restart your Macintosh[®].

For Mac OS® X 10.2.4 to 10.2.8 users: Go to step 7.

For Mac OS® X 10.3 or greater users: Go to step **5**.




Please see the User's Guide on the CD-ROM to install the PS driver (Brother's BR-Script Driver).

The Brother software will search for the Brother printer. During this time the following screen will appear.





If more than one printer is available, the following list appears. Choose the printer you wish to connect, and then click **OK**.



6 When this screen appears, click **OK**.



- For Mac OS[®] X 10.3 or greater users: Setup is now complete.
- When this screen appears, click **Add**.



Choose USB.



Choose your printer, and then click Add.



10 Click Print Center, then Quit Print Center.



OK!


For Mac OS[®] X 10.2.4 to 10.2.8 users: Setup is now complete.



For network interface cable users

Connecting the printer to your $\mathsf{Macintosh}^{\texttt{®}}$ and installing the driver

Connect the network interface cable to the printer, and then connect it to a free port on your hub.



Turn on the printer power switch.



Click Install Printer Driver on the menu screen.



Click Network cable users and follow the on-screen instructions. Then, restart your Macintosh®.

For Mac OS® X 10.2.4 to 10.2.8 users: Go to step 7.

For Mac OS® X 10.3 or greater users: Go to step 5.




Please see the Network User's Guide on the CD-ROM to install the PS driver (Brother's BR-Script Driver).

The Brother software will search for the Brother printer. During this time the following screen will appear.






If more than one printer is available, the following list appears. Choose the printer you wish to connect, and then click **OK**.



- If there is more than one of the same printer model connected on your network, the Ethernet address (MAC address) will be displayed after the model name.
- 6 When this screen appears, click **OK**.




- For Mac OS® X 10.3 or greater users: Setup is now complete.
- When this screen appears, click **Add**.



8 Make the following selection.



9 Choose your printer, and then click **Add**.





If there is more than one of the same printer model connected on your network, the Ethernet address (MAC address) will be displayed after the model name.

10 Click Print Center, then Quit Print Center.





OK!

For Mac OS[®] X 10.2.4 to 10.2.8 users: Setup is now complete.



Shipment of the printer



Caution

- Once your printer has been set up and used, we do not recommend that it be moved or shipped unless absolutely necessary.
- Color laser printers are complex printing devices. Moving the printer or shipping it without properly removing
 the installed supplies can result in SEVERE damage to the printer. As a result, your printer may not operate
 properly afterwards.
- If the printer must be shipped, see the supplied Repacking Information insertion or visit
 <u>http://solutions.brother.com</u> for detailed, step-by-step instructions on how to properly prepare your printer for transport.
- Failure to properly prepare the printer for shipping according to the instructions located at http://solutions.brother.com may VOID YOUR WARRANTY.
- If for any reason you must ship your printer, carefully package the printer to avoid any damage during transit. We recommend that you save and use the original packaging. The printer should also be adequately insured with the carrier.

Trademarks

The Brother logo is a registered trademark of Brother Industries, Ltd.

Apple, the Apple Logo, Macintosh and TrueType are registered trademarks of Apple Inc. in the United States and other countries.

Microsoft, MS-DOS and Windows are registered trademarks of Microsoft Corporation in the U.S. and other countries.

Windows Vista is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.

Java and all Java-based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and other countries.

All other terms and brand and product names mentioned in this Quick Setup Guide are registered trademarks of their respective companies.

Compilation and Publication

This manual has been compiled and published, under the supervision of Brother Industries Ltd., covering the latest product descriptions and specifications.

The contents of this manual and the specifications of this product are subject to change without notice.

Brother reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication.

This product is designed for use in a professional environment.

Copyright and License

© 2007 Brother Industries, Ltd. © 1998-2007 TROY Group, Inc. © 1983-2007 PACIFIC SOFTWORKS INC. This product includes the "KASAGO TCP/IP" software developed by Elmic Systems, Inc. © 2007 Devicescape Software, Inc. This product includes RSA BSAFE Cryptographic software from RSA Security Inc. ALL RIGHTS RESERVED.