NOTE

NOTE specifies the operating environment, conditions for installation, or special conditions of use.

**CEE-ENG** Version 0

# Quick Setup Guide

MFC-J5320DW

Read the Product Safety Guide first, then read this Quick Setup Guide for the correct installation procedure.





Watch our FAQ Videos for help with setting up your Brother machine.

solutions.brother.com/videos

Visit the Brother support website http://support.brother.com


# Unpack the machine and check the components

- 1. Remove the protective tape and film covering the machine, and also from the Touchscreen.
- 2. Make sure you have all components. The components included in the box may differ depending on your country.




Introductory Ink Cartridges [x4] Black Yellow

Cyan Magenta (Approx. 65% yield of the replacement cartridge (High Yield) >> Online User's Guide)



**Quick Setup Guide Product Safety Guide** 



**Maintenance Sheet** 

Do not exceed this



**CD-ROM** 



**Power Cord** 



#### **WARNING**

Plastic bags are used in the packing of your machine. To avoid the danger of suffocation, keep these plastic bags away from babies and children. Plastic bags are not toys.


#### NOTE

- · Save all packing materials and the box in case for any reason you must ship your
- You must purchase the correct interface cable for the interface you want to use (for USB or network connection).


We recommend using a USB 2.0 cable (Type A/B) that is no more than 2 metres

**Network cable** Use a straight-through Category5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.

# Load plain A4 paper



Pull the paper tray completely out of the machine.





Fan the paper well and load it in the tray.




Pull out the paper support 1, and unfold the paper support flap 2.




# Connect power cord and telephone line cord

If you are not using your machine as a fax, connect the power cord and go to 3.




Connect the power cord. Lift the scanner cover.




Connect the telephone line cord. Use the socket marked LINE and guide the cord out the back of the machine.

If you are sharing one telephone line with an external telephone, connect it as shown below.



1. Extension telephone 2. External telephone




Close the scanner cover.

# Install introductory ink cartridges




Open the ink cartridge cover 1.



Follow the Touchscreen instructions to install the ink cartridges. The machine will prepare the ink tube system for printing.

## NOTE

You can adjust the angle of the control panel by lifting it.



# **Machine Settings**

When the machine has finished the initial cleaning process, follow the Touchscreen instructions to configure the machine settings.

- Check print quality
- Set date and time
- · Print the installation sheet


# Choose your language


- 1. Press ii (Settings).
- Press All Settings.
- Press ▲ or ▼ to display Initial Setup. Press Initial Setup.


- 4. Press ▲ or ▼ to display Local Language. Press Local Language.
- Press your language.
- 6. Press .




# Choose your method













# Connect to your device and install software



#### For Wireless Networks

To connect additional computers, repeat Method A for each computer.

### Method A Setup from the computer

Make sure that you are logged on with Administrator rights.



Put the CD-ROM into your CD-ROM drive. If you do not have a CD-ROM drive, download the software at:

For Windows®: solutions.brother.com/windows
For Macintosh: solutions.brother.com/mac





( Macintosh )

Follow the on-screen instructions to continue installation.

A USB cable may be needed in some cases.




**Finish** 

Finish

### Method B Manual setup using the Setup Wizard

### ■ Set up your machine

Write your wireless access point/router information in the area below.
 This information may be hidden on the bottom of the wireless access point/router. If you cannot find it, ask your network administrator or wireless access point/router manufacturer.



2. Press wifi on your Brother machine's Touchscreen, and then press Setup Wizard.

When Switch Network interface to wireless? is displayed, press Yes.

- 3. Select the SSID you wrote down in 1. Press OK.
- **4.** If the machine prompts you to enter a Network Key, enter the key you wrote down in **1**. Press OK.
- **5.** Press Yes to apply your settings.


## ■ Install Brother iPrint&Scan




You can print from and scan to mobile devices using our free application "Brother iPrint&Scan."

Download and install the application from solutions.brother.com/ips.







Put the CD-ROM into your CD-ROM drive. If you do not have a CD-ROM drive, download the software at: For Windows®: solutions.brother.com/windows
For Macintosh: solutions.brother.com/mac





( Macintosh )

Follow the on-screen instructions to continue installation.


# 苦

### For Wired Networks

To connect additional computers, repeat this procedure for each computer.

### ■ Connect the network cable

### ■ Install MFL-Pro Suite



Make sure that you are logged on with Administrator rights.

Put the CD-ROM into your CD-ROM drive. If you do not have a CD-ROM drive, download the software at:
For Windows®:

solutions.brother.com/windows
For Macintosh:
solutions.brother.com/mac







Follow the on-screen instructions to continue installation.



## For USB Connections


# ■ Install MFL-Pro Suite



Make sure that you are logged on with Administrator rights.

# Put the CD-ROM into your CD-ROM drive. If you do not have a CD-ROM drive, download the software at: solutions.brother.com/windows

Follow the on-screen instructions.




■ Connect the USB cable

Follow the on-screen instructions to continue installation.




# ■ Connect the USB cable



### ■ Install MFL-Pro Suite

Download



Make sure that you are logged on with Administrator rights.

# Put the CD-ROM into your CD-ROM drive. If you do not have a CD-ROM drive, download the software at: solutions.brother.com/mac





Internet access is required.
Follow the on-screen instructions to continue installation.