



D02XKD001-00
ASA/GLF
Version 0

Quick Setup Guide

DCP-B7600DB / DCP-B7620DW / DCP-B7620DWB / DCP-B7640DW / DCP-B7640DWB /
MFC-B7810DW / MFC-B7810DWB / MFC-B7811DW

Read the *Product Safety Guide* first, then read this *Quick Setup Guide* for the correct installation procedure.
Not all models are available in all countries.

brother


EN



The latest manuals are available at the Brother support website:
support.brother.com/manuals


Unpack the machine and check the components

Remove the protective tape or film covering the machine and the supplies.




AC Power Cord

A




Drum Unit

B



Toner Cartridge



Quick Setup Guide



Product Safety Guide

NOTE:

- The components included in the box may differ depending on your country.
- The available connection interfaces vary depending on the model.
If you use a wired connection, you must purchase the correct cable for the interface you want to use.

• USB cable





We recommend using a USB 2.0 cable (Type A/B) that is no more than 2 metres long.

• Network cable (for wired network models only)




Use a straight-through Category 5 (or greater) twisted-pair cable.

- The screens and images in this *Quick Setup Guide* show the MFC-B7810DW.
- Save all packing materials and the box in case you must ship your machine.


1 Remove the packing materials and install the toner cartridge and drum unit assembly





Remove the orange part.





Push firmly.





2 Load paper in the paper tray



Do not exceed this mark.



3 Connect the power cord and turn the machine on



4 Select your country/language (Initial setup only)

After turning the machine on, you may be required to set your country or language (depending on your machine).


If required, follow the on-screen instructions.

5 Select your language (if needed)

- 1. Press **Menu**.
- 2. Press **▲** or **▼** to display [Initial Setup], and then press **OK**.
- 3. Press **▲** or **▼** to display [Local Language], and then press **OK**.
- 4. Press **▲** or **▼** to select your language, and then press **OK**.
- 5. Press **Stop/Exit**.

6 Connect the telephone line cord (For MFC models only)


If you do not plan to use the fax feature on this machine, go to step **7**.



7 Connect your computer or mobile device to your machine

Follow these steps to complete the setup using one of the connection types available on your machine.

Visit setup.brother.com to download and install Brother software.



NOTE:
For Windows only, CD installation is also available (for some countries).

Follow the on-screen instructions and prompts.

Setup Finished

You can now print and scan using your machine.

Important Notice for Network Security:
The default password to manage this machine's settings is located on the back of the machine and marked "Pwd". We recommend immediately changing the default password to protect your machine from unauthorised access.

Can't Connect? Check the following:

Restart your wireless access point or router. If this is not possible, go to the next step.

Disconnect the cable.

Restart your machine and computer, and then go to **7**.

If still unsuccessful, go to **8**.


If still unsuccessful, visit support.brother.com for FAQs and Troubleshooting.

8 Manual wireless setup (Wireless models)

If the wireless setup is unsuccessful, set up the connection manually.

Find your SSID (Network Name) and Network Key (Password) on your wireless access point or router and write them in the table provided below.

SSID (Network Name)	
Network Key (Password)	



Press **Menu**, and then select [Network] > [WLAN (Wi-Fi)] > [Find Network]. Follow the LCD instructions.

If you cannot find this information, ask your network administrator or wireless access point or router manufacturer.

Select the SSID (Network Name) for your access point or router and enter the Network Key (Password).

- For DCP models:
Press and hold (or press repeatedly) **▲** or **▼** to select one of the following characters:
0123456789abcdefghijklmnopqrstuvwxyz
ABCDEFGHIJKLMNOPQRSTUVWXYZ
(space)!"#%&'()*+,-./:;<=>?@[\\]^_`{|}~

When the wireless setup is successful, the LCD displays [Connected].

Go to **7** to install software.

If the setup is unsuccessful, restart your Brother machine and your wireless access point or router, and repeat **8**. If still unsuccessful, visit support.brother.com.