

Model Name: QL-820NWB

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.2W	0.3W	0min	-
USB	1.0W	0.3W	0min	60min
Wi-Fi	1.4W	0.3W	0min	-
Bluetooth	1.1W	0.3W	0min	-
All network ports activated and connected	1.6W	0.3W	0min	-

How to enable/disable Wi-Fi

To activate the wireless function:

1. Press and hold the ⏻ (Power) button to turn the Label Printer on.
2. Press the Menu button.
3. Press the [▲] or [▼] button to select the [WLAN] menu, and then press the [OK] button.
4. Press the [▲] or [▼] button to select [WLAN (On/Off)], and then press the [OK] button.
5. Press the [▲] or [▼] button to select [On], and then press the [OK] button.

To deactivate the wireless function:

1. Press the Menu button.
2. Press the [▲] or [▼] button to select the [WLAN] menu, and then press the [OK] button.
3. Press the [▲] or [▼] button to select [WLAN (On/Off)], and then press the [OK] button.
4. Press the [▲] or [▼] button to select [Off], and then press the [OK] button.

How to enable/disable Bluetooth

To activate the Bluetooth function:

1. Press and hold the ⏻ (Power) button to turn the Label Printer on.
2. Press the Menu button.
3. Press the [▲] or [▼] button to select the [Bluetooth] menu, and then press the [OK] button.
4. Press the [▲] or [▼] button to select [Bluetooth (On/Off)], and then press the [OK] button.
5. Press the [▲] or [▼] button to select [On], and then press the [OK] button.

To deactivate the Bluetooth function:

1. Press the Menu button.
2. Press the [▲] or [▼] button to select the [Bluetooth] menu, and then press the [OK] button.
3. Press the [▲] or [▼] button to select [Bluetooth (On/Off)], and then press the [OK] button.
4. Press the [▲] or [▼] button to select [Off], and then press the [OK] button.