

Linking to a bar code reader and printing bar code data **barcode.lbx**

Media: 51mm×26mm



1 bar code object

1 image object

(Specify the text object as uneditable, and then convert it to an image. (Select the “Text Cannot Be Edited” check box on the [Expanded] tab of the Text Properties.))

Using the Transfer Manager, specify the template as number 1, and then transfer it.


If the data outputted from the bar code reader is “1231231”:

barcode.txt

1231231

Specify the following in P-touch Template settings tool.

- ① Select “P-touch Template” beside “Default Command Mode”.
- ② Specify template number 1.
- ③ Select “Received Data Size” under “Trigger for P-touch Template Printing”.
- ④ Specify “7” beside “Received Data Size”.



Print result

